

InvenSense Inc. 1197 Borregas Ave, Sunnyvale, CA 94089 U.S.A. Tel: +1 (408) 988-7339 Fax: +1 (408) 988-8104 Website: www.invensense.com

Document Number: RM-MPU-9150A-00 Revision: 4.0 Release Date: 09/12/2012

MPU-9150 Register Map and Descriptions Revision 4.0



CONTENTS

1	REVIS	SION HISTORY	. 4
2	PURP	OSE AND SCOPE	. 5
3		STER MAP FOR GYROSCOPE AND ACCELEROMETER	
4	REGI	STER DESCRIPTIONS FOR GYROSCOPE AND ACCELEROMETER	
	4.1	REGISTERS 13 TO 16 – SELF TEST REGISTERS	
	4.2	REGISTER 25 – SAMPLE RATE DIVIDER	
	4.3	REGISTER 26 – CONFIGURATION	13
	4.4	REGISTER 27 – GYROSCOPE CONFIGURATION	14
	4.5	REGISTER 28 – ACCELEROMETER CONFIGURATION	15
	4.6	REGISTER 31 – MOTION DETECTION THRESHOLD	
	4.7	REGISTER 32 – MOTION DETECTION DURATION	
	4.8	REGISTER 33 – ZERO MOTION DETECTION THRESHOLD	19
	4.9	REGISTER 34 – ZERO MOTION DETECTION DURATION	19
	4.10	REGISTER 35 – FIFO ENABLE	
	4.11	REGISTER 36 – I ² C MASTER CONTROL	
	4.12	REGISTERS 37 TO 39 – I ² C SLAVE 0 CONTROL	23
	4.13	REGISTERS 40 TO 42 – I ² C SLAVE 1 CONTROL	26
	4.14	REGISTERS 43 TO 45 – I ² C SLAVE 2 CONTROL	26
	4.15	REGISTERS 46 TO 48 – I ² C SLAVE 3 CONTROL	26
	4.16	REGISTERS 49 TO 53 – I ² C SLAVE 4 CONTROL	27
	4.17	REGISTER 54 – I ² C MASTER STATUS	29
	4.18	REGISTER 55 – INT PIN / BYPASS ENABLE CONFIGURATION	30
	4.19	REGISTER 56 – INTERRUPT ENABLE	32
	4.20	REGISTER 58 – INTERRUPT STATUS	33
	4.21	REGISTERS 59 TO 64 – ACCELEROMETER MEASUREMENTS	34
	4.22	REGISTERS 65 AND 66 – TEMPERATURE MEASUREMENT	35
	4.23	REGISTERS 67 TO 72 – GYROSCOPE MEASUREMENTS	36
	4.24	REGISTERS 73 TO 96 – EXTERNAL SENSOR DATA	37
	4.25	REGISTER 97 – MOTION DETECTION STATUS	39
	4.26	REGISTER 99 – I ² C SLAVE 0 DATA OUT	40
	4.27	REGISTER 100 – I ² C SLAVE 1 DATA OUT	40
	4.28	REGISTER 101 – I ² C SLAVE 2 DATA OUT	41
	4.29	REGISTER 102 – I ² C SLAVE 3 DATA OUT	41



	4.30	REGISTER 103 – I ² C MASTER DELAY CONTROL	42
	4.31	REGISTER 104 – SIGNAL PATH RESET	43
	4.32	REGISTER 105 – MOTION DETECTION CONTROL	44
	4.33	REGISTER 106 – USER CONTROL	45
	4.34	REGISTER 107 – POWER MANAGEMENT 1	46
	4.35	REGISTER 108 – POWER MANAGEMENT 2	
	4.36	REGISTER 114 AND 115 – FIFO COUNT REGISTERS	49
	4.37	REGISTER 116 – FIFO READ WRITE	
	4.38	Register 117 – Who Am I	51
5	REGI	STER MAP FOR MAGNETOMETER	
	5.1	REGISTER MAP DESCRIPTION	
c	DEAL		
Ø	REGI	STER DETAILED DESCRIPTIONS FOR MAGNETOMETER	
o	6.1	WIA: DEVICE ID	55
O		WIA: DEVICE ID	55 55
O	6.1	WIA: DEVICE ID	55 55
0	6.1 6.2	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA	55 55 55 56
o	6.1 6.2 6.3	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA ST2: STATUS 2	55 55 55 56 57
o	6.1 6.2 6.3 6.4	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA ST2: STATUS 2 CNTL: CONTROL	55 55 55 56 57 57
o	6.1 6.2 6.3 6.4 6.5	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA ST2: STATUS 2 CNTL: CONTROL RSV: RESERVED	55 55 56 57 57 57
o	 6.1 6.2 6.3 6.4 6.5 6.6 	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA ST2: STATUS 2 CNTL: CONTROL RSV: RESERVED ASTC: SELF TEST CONTROL	55 55 56 57 57 58 58
o	 6.1 6.2 6.3 6.4 6.5 6.6 6.7 	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA ST2: STATUS 2 CNTL: CONTROL RSV: RESERVED ASTC: SELF TEST CONTROL TS1, TS2: TEST 1, 2	55 55 56 57 57 57 58 58 58
0	 6.1 6.2 6.3 6.4 6.5 6.6 6.7 6.8 	WIA: DEVICE ID INFO: INFORMATION ST1: STATUS 1 HXL TO HZH: MEASUREMENT DATA ST2: STATUS 2 CNTL: CONTROL RSV: RESERVED ASTC: SELF TEST CONTROL	55 55 56 57 57 57 58 58 58



1 Revision History

Revision Date	Revision	Description
06/01/2011	1.0	Initial Release
06/14/2011	2.0	Updated registers with enhanced functionality.
10/24/2011	3.0	Updates for Rev D Silicon Edits for Clarity Updated accelerometer sensitivity specifications (Section 4.22)
		Updated reset value for register 107 (section 3) Added Self-Test registers (section 3) Added description of Self-Test registers (section 4.1) Updated register 27 with gyro self-test bits (section 4.4) Updated accel self-test instructions (section 4.5) Revised temperature register section (section 4.19)
09/12/2012	4.0	Corrections in registers 107 and 108 (section 4.30)

O ANOF



2 Purpose and Scope

This document provides preliminary information regarding the register map and descriptions for the MPU-9150[™] Motion Processing Unit[™] or MPU[™].

The MPU-9150 Motion Processing Unit is the world's first motion processing solution with integrated 9-Axis sensor fusion using its field-proven and proprietary MotionFusion[™] engine for handset and tablet applications, game controllers, motion pointer remote controls, and other consumer devices. The MPU-9150 has an embedded 3-axis MEMS gyroscope, a 3-axis MEMS accelerometer, a 3-axis MEMS magnetometer and a Digital Motion Processor[™] (DMP[™]) hardware accelerator engine with an auxiliary I²C port that interfaces to 3rd party digital sensors such as pressure sensors. The MPU-9150's 9-axis MotionFusion combines acceleration and rotational motion plus heading information into a single data stream for the application. This MotionProcessing[™] technology integration provides a smaller footprint and has inherent cost advantages compared to discrete gyroscope, accelerometer, plus magnetometer solutions. The MPU-9150 is also designed to interface with multiple non-inertial digital sensors, such as pressure sensors, on its auxiliary I²C port to produce a 10-Axis sensor fusion output. The MPU-9150 is a 3rd generation motion processor and is footprint compatible with the MPU-60X0 and MPU-30X0 families.

The MPU-9150 features three 16-bit analog-to-digital converters (ADCs) for digitizing the gyroscope outputs, three 16-bit ADCs for digitizing the accelerometer outputs, and three 13-bit ADCs for digitizing the magnetometer outputs. For precision tracking of both fast and slow motions, the parts feature a user-programmable gyroscope full-scale range of ± 250 , ± 500 , ± 1000 , and $\pm 2000^{\circ}$ /sec (dps), a user-programmable accelerometer full-scale range of $\pm 2g$, $\pm 4g$, $\pm 8g$, and $\pm 16g$, and a magnetometer full-scale range of $\pm 1200\mu$ T.

The MPU-9150 is a multi-chip module (MCM) consisting of two dies integrated into a single LGA package. One die houses the 3-Axis gyroscope and the 3-Axis accelerometer. The other die houses the AK9875C 3-Axis magnetometer from Asahi Kasei Microdevices Corporation.

An on-chip 1024 Byte FIFO buffer helps lower system power consumption by allowing the system processor to read the sensor data in bursts and then enter a low-power mode as the MPU collects more data. With all the necessary on-chip processing and sensor components required to support many motion-based use cases, the MPU-9150 uniquely supports a variety of advanced motion-based applications entirely on-chip. The MPU-9150 thus enables low-power MotionProcessing in portable applications with reduced processing requirements for the system processor. By providing an integrated MotionFusion output, the DMP in the MPU-9150 offloads the intensive MotionProcessing computation requirements from the system processor, minimizing the need for frequent polling of the motion sensor output.

Communication with all registers of the device is performed using l^2C at 400kHz. Additional features include an embedded temperature sensor and an on-chip oscillator with ±1% variation over the operating temperature range.

For more detailed information for the MPU-9150 device, please refer to the MPU-9150 Product Specification document.



3 Register Map for Gyroscope and Accelerometer

The register map for the MPU-9150's Gyroscope and Accelerometer section is listed below. The Magnetometer's register map can be found in section 5.

Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
0D	13	SELF_TEST_X	R/W		XA_TEST[4-2]				XG_TEST[4-0]		
0E	14	SELF_TEST_Y	R/W		YA_TEST[4-2]		YG_TEST[4-0]				
0F	15	SELF_TEST_Z	R/W		ZA_TEST[4-2]				ZG_TEST[4-0]		
10	16	SELF_TEST_A	R/W	RESE	RESERVED XA_TEST[1-0] YA_TEST[1-0]					ZA_TE	ST[1-0]
19	25	SMPLRT_DIV	R/W				SMPLRT	_DIV[7:0]			
1A	26	CONFIG	R/W	-	-	E	XT_SYNC_SET[2	:0]		DLPF_CFG[2:0]	
1B	27	GYRO_CONFIG	R/W	XG_ST	YG_ST	ZG_ST	FS_SI	EL [1:0]	-	-	-
1C	28	ACCEL_CONFIG	R/W	XA_ST	YA_ST	ZA_ST	AFS_S	SEL[1:0]		ACCEL_HPF[2:0]
1D	29	FF_THR	R/W				FF_Th	IR[7:0]			
1E	30	FF_DUR	R/W				FF_DU	JR[7:0]			
1F	31	MOT_THR	R/W				MOT_T	HR[7:0]			
20	32	MOT_DUR	R/W				MOT_D	UR[7:0]			
21	33	ZRMOT_THR	R/W				ZRMOT_	THR[7:0]			
22	34	ZRMOT_DUR	R/W				ZRMOT_	DUR[7:0]			
23	35	FIFO_EN	R/W	TEMP _FIFO_EN	XG _FIFO_EN	YG _FIFO_EN	ZG _FIFO_EN	ACCEL _FIFO_EN	SLV2 _FIFO_EN	SLV1 _FIFO_EN	SLV0 _FIFO_EN
24	36	I2C_MST_CTRL	R/W	MULT _MST_EN	WAIT _FOR_ES	SLV_3 _FIFO_EN	I2C_MST _P_NSR		I2C_MST	_CLK[3:0]	
25	37	I2C_SLV0_ADDR	R/W	I2C_SLV0 _RW			120	C_SLV0_ADDR[6	6:0]		
26	38	I2C_SLV0_REG	R/W				I2C_SLV0	_REG[7:0]			
27	39	I2C_SLV0_CTRL	R/W	I2C_SLV0 _EN	I2C_SLV0 _BYTE_SW	I2C_SLV0 _REG_DIS	I2C_SLV0 _GRP		I2C_SLV0	D_LEN[3:0]	
28	40	I2C_SLV1_ADDR	R/W	I2C_SLV1 _RW			120	C_SLV1_ADDR[6	6:0]		
29	41	I2C_SLV1_REG	R/W				I2C_SLV1	_REG[7:0]			
2A	42	I2C_SLV1_CTRL	R/W	I2C_SLV1 _EN	I2C_SLV1 _BYTE_SW	I2C_SLV1 _REG_DIS	I2C_SLV1 _GRP		I2C_SLV1	1_LEN[3:0]	
2B	43	I2C_SLV2_ADDR	R/W	I2C_SLV2 _RW			120	C_SLV2_ADDR[6	ð:0]		
2C	44	I2C_SLV2_REG	R/W		-		I2C_SLV2	_REG[7:0]			
2D	45	I2C_SLV2_CTRL	R/W	I2C_SLV2 _EN	I2C_SLV2 _BYTE_SW	I2C_SLV2 _REG_DIS	I2C_SLV2 _GRP		I2C_SLV2	2_LEN[3:0]	
2E	46	I2C_SLV3_ADDR	R/W	I2C_SLV3 _RW			120	C_SLV3_ADDR[6	ð:0]		
2F	47	I2C_SLV3_REG	R/W					_REG[7:0]			
30	48	I2C_SLV3_CTRL	R/W	I2C_SLV3 _EN	I2C_SLV3 _BYTE_SW	I2C_SLV3 _REG_DIS	I2C_SLV3 _GRP		I2C_SLV3	3_LEN[3:0]	
31	49	I2C_SLV4_ADDR	R/W	I2C_SLV4 _RW			120	C_SLV4_ADDR[6	5:0]		
32	50	I2C_SLV4_REG	R/W				I2C_SLV4	_REG[7:0]			
33	51	I2C_SLV4_DO	R/W				I2C_SLV	4_DO[7:0]			
34	52	I2C_SLV4_CTRL	R/W	I2C_SLV4 _EN	I2C_SLV4 _INT_EN	I2C_SLV4 _REG_DIS		l	2C_MST_DLY[4:	0]	
35	53	I2C_SLV4_DI	R				I2C_SLV	4_DI[7:0]			



Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	
36	54	I2C_MST_STATUS	R	PASS_ THROUGH	I2C_SLV4 _DONE	I2C_LOST _ARB	I2C_SLV4 _NACK	I2C_SLV3 _NACK	I2C_SLV2 _NACK	I2C_SLV1 _NACK	I2C_SLV0 _NACK	
37	55	INT_PIN_CFG	R/W	INT_LEVEL	INT_OPEN	LATCH _INT_EN	INT_RD _CLEAR	FSYNC_ INT_LEVEL	FSYNC _INT_EN	I2C _BYPASS _EN	CLKOUT _EN	
38	56	INT_ENABLE	R/W	FF_EN	MOT_EN	ZMOT_EN	FIFO _OFLOW _EN	I2C_MST _INT_EN	-	·	DATA _RDY_EN	
3A	58	INT_STATUS	R	FF_INT	MOT_INT	ZMOT _INT	FIFO _OFLOW _INT	I2C_MST _INT	-		DATA _RDY_INT	
3B	59	ACCEL_XOUT_H	R				ACCEL_>	OUT[15:8]				
3C	60	ACCEL_XOUT_L	R				ACCEL_	KOUT[7:0]				
3D	61	ACCEL_YOUT_H	R		ACCEL_YOUT[15:8]							
3E	62	ACCEL_YOUT_L	R				ACCEL_	YOUT[7:0]				
3F	63	ACCEL_ZOUT_H	R				ACCEL_Z	OUT[15:8]				
40	64	ACCEL_ZOUT_L	R				ACCEL_	ZOUT[7:0]				
41	65	TEMP_OUT_H	R				TEMP_C	DUT[15:8]				
42	66	TEMP_OUT_L	R				TEMP_	OUT[7:0]				
43	67	GYRO_XOUT_H	R				GYRO_X	OUT[15:8]				
44	68	GYRO_XOUT_L	R				GYRO_>	OUT[7:0]				
45	69	GYRO_YOUT_H	R				GYRO_Y	OUT[15:8]				
46	70	GYRO_YOUT_L	R				GYRO_1	'OUT[7:0]				
47	71	GYRO_ZOUT_H	R				GYRO_Z	OUT[15:8]				
48	72	GYRO_ZOUT_L	R				GYRO_2	OUT[7:0]				
49	73	EXT_SENS_DATA_00	R				EXT_SENS_	DATA_00[7:0]				
4A	74	EXT_SENS_DATA_01	R				EXT_SENS_	DATA_01[7:0]				
4B	75	EXT_SENS_DATA_02	R				EXT_SENS_	DATA_02[7:0]				
4C	76	EXT_SENS_DATA_03	R				EXT_SENS_	DATA_03[7:0]				
4D	77	EXT_SENS_DATA_04	R				EXT_SENS_	DATA_04[7:0]				
4E	78	EXT_SENS_DATA_05	R				EXT_SENS_	DATA_05[7:0]				
4F	79	EXT_SENS_DATA_06	R				EXT_SENS_	DATA_06[7:0]				
50	80	EXT_SENS_DATA_07	R				EXT_SENS_	DATA_07[7:0]				
51	81	EXT_SENS_DATA_08	R				EXT_SENS_	DATA_08[7:0]				
52	82	EXT_SENS_DATA_09	R				EXT_SENS_	DATA_09[7:0]				
53	83	EXT_SENS_DATA_10	R				EXT_SENS_	DATA_10[7:0]				
54	84	EXT_SENS_DATA_11	R				EXT_SENS_	DATA_11[7:0]				
55	85	EXT_SENS_DATA_12	R				EXT_SENS_	DATA_12[7:0]				
56	86	EXT_SENS_DATA_13	R				EXT_SENS_	DATA_13[7:0]				
57	87	EXT_SENS_DATA_14	R				EXT_SENS_	DATA_14[7:0]				
58	88	EXT_SENS_DATA_15	R				EXT_SENS_	DATA_15[7:0]				
59	89	EXT_SENS_DATA_16	R				EXT_SENS_	DATA_16[7:0]				
5A	90	EXT_SENS_DATA_17	R		EXT_SENS_DATA_17[7:0]							
5B	91	EXT_SENS_DATA_18	R		EXT_SENS_DATA_18[7:0]							
5C	92	EXT_SENS_DATA_19	R				EXT_SENS_	DATA_19[7:0]				



Addr (Hex)	Addr (Dec.)	Register Name	Serial I/F	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0			
5D	93	EXT_SENS_DATA_20	R		EXT_SENS_DATA_20[7:0]									
5E	94	EXT_SENS_DATA_21	R				EXT_SENS_	DATA_21[7:0]						
5F	95	EXT_SENS_DATA_22	R				EXT_SENS_	DATA_22[7:0]						
60	96	EXT_SENS_DATA_23	R		EXT_SENS_DATA_23[7:0]									
61	97	MOT_DETECT_STAT US	R	MOT _XNEG	MOT _XPOS	MOT _YNEG	MOT _YPOS	MOT _ZNEG	MOT _ZPOS		MOT _ZRMOT			
63	99	I2C_SLV0_DO	R/W				I2C_SLV	0_DO[7:0]						
64	100	I2C_SLV1_DO	R/W		I2C_SLV1_DO[7:0]									
65	101	I2C_SLV2_DO	R/W		I2C_SLV2_DO[7:0]									
66	102	I2C_SLV3_DO	R/W		I2C_SLV3_DO[7:0]									
67	103	I2C_MST_DELAY_CT RL	R/W	DELAY_ES _SHADOW	-	-	I2C_SLV4 _DLY_EN	I2C_SLV3 _DLY_EN	I2C_SLV2 _DLY_EN	I2C_SLV1 _DLY_EN	I2C_SLV0 _DLY_EN			
68	104	SIGNAL_PATH_RES ET	R/W	-	-	-	-		GYRO _RESET	ACCEL _RESET	TEMP _RESET			
69	105	MOT_DETECT_CTRL	R/W	-	-	ACCEL_ON	_DELAY[1:0]	[1:0] FF_COUNT[1:0]		MOT_COUNT[1:0]				
6A	106	USER_CTRL	R/W	-	FIFO_EN	I2C_MST _EN	I2C_IF _DIS		FIFO _RESET	I2C_MST _RESET	SIG_COND _RESET			
6B	107	PWR_MGMT_1	R/W	DEVICE _RESET	SLEEP	CYCLE		TEMP_DIS		CLKSEL[2:0]				
6C	108	PWR_MGMT_2	R/W	LP_WAKE	_CTRL[1:0]	STBY_XA	STBY_YA	STBY_ZA	STBY_XG	STBY_YG	STBY_ZG			
72	114	FIFO_COUNTH	R/W	-	-	-		-	F	IFO_COUNT[10:	8]			
73	115	FIFO_COUNTL	R/W				FIFO_CO	DUNT[7:0]						
74	116	FIFO_R_W	R/W				FIFO_D	ATA[7:0]						
75	117	WHO_AM_I	R	-			WHO_4	AM_I[6:1]			-			

<u>Note:</u> Register Names ending in _H and _L contain the high and low bytes, respectively, of an internal register value.

In the detailed register tables that follow, register names are in capital letters, while register values are in capital letters and italicized. For example, the ACCEL_XOUT_H register (Register 59) contains the 8 most significant bits, ACCEL_XOUT[15:8], of the 16-bit X-Axis accelerometer measurement, ACCEL_XOUT.

The reset value is 0x00 for all registers other than the registers below.

- Register 107: 0x40.
- Register 117: 0x68.



4 Register Descriptions for Gyroscope and Accelerometer

This section details each register within the MPU-9150's Gyroscope and Accelerometer sections.

Note: The device will come up in sleep mode upon power up.

4.1 Registers 13 to 16 – Self Test Registers SELF_TEST_X, SELF_TEST_Y, SELF_TEST_Z, and SELF_TEST_A

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0		
0D	13	XA_TEST[4-2]			XG_TEST[4-0]						
0E	14	Y	YA_TEST[4-2]			YG_TEST[4-0]					
0F	15	Z	ZA_TEST[4-2]			ZG_TEST[4-0]					
10	16	RESER	RVED	XA_TE	ST[1-0]	YA_TE	ST[1-0]	ZA_TES	ST[1-0]		

Description:

These registers are used to hold the Factory trim values of the self-test response for the gyroscope.

Following is a description of the relative self-test method for the gyroscope and accelerometer.

Gyroscope Hardware Self-Test: Relative Method

Gyroscope self-test permits users to test the mechanical and electrical portions of the gyroscope via the procedure in *Obtaining the Gyroscope Factory Trim (FT) Value* below.

When self-test is activated, the on-board electronics will actuate the appropriate sensor. Please refer to the register 27 for the corresponding bits to activate the self-test. This actuation will move the sensor's proof masses over a distance equivalent to a pre-defined Coriolis force. This proof mass displacement results in a change in the sensor output, which is reflected in the output signal. The output signal is used to observe the self-test response.

The self-test response (STR) is defined as follows:

SelfTest Response =

Gyroscope Output with Self-Test Enabled – Gyroscope Output with Self-Test Disabled

The self-test response is stored in the sensor data output registers 67 - 72. This self-test-response is used to determine whether the part has passed or failed self-test by finding the change from factory trim of the self-test response as follows:

Change from Factory Trim of the Self-Test Response(%) =
$$\frac{(STR - FT)}{FT}$$

where,

FT = *Factory trim value of selftest response, available via MotionApps software*

This change from factory trim of the self-test response must be within the limits provided in the MPU-9150 Product Specification document for the part to pass self-test. Otherwise, the part is deemed to have failed self-test.

Obtaining the Gyroscope Factory Trim (FT) Value



The following procedure obtains the Factory trim value of the self-test response (FT) mentioned above.

The Factory trim value of the self-test response (FT) is calculated as shown below. FT[Xg], FT[Yg], and FT[Zg] refer to the factory trim (FT) values for the gyroscope X, Y, and Z axes, respectively.

When performing self-test for the gyroscope, the full-scale range should be set to ±250dps.

$\begin{cases} FT [Xg] = 25 * 131 * 1.046^{(XG_TEST-1)} \\ FT [Xg] = 0 \end{cases}$	if XG_TEST $\neq 0$ if XG_TEST = 0
$\begin{cases} FT [Yg] = -25 * 131 * 1.046^{(YG_TEST-1)} \\ FT [Yg] = 0 \end{cases}$	if YG_TEST $\neq 0$ if YG_TEST = 0
$\begin{cases} FT [Zg] = 25 * 131 * 1.046^{(ZG_TEST-1)} \\ FT [Zg] = 0 \end{cases}$	if ZG_TEST $\neq 0$ if ZG_TEST = 0

Accelerometer Hardware Self-Test: Relative Method

Accelerometer self-test permits users to test the mechanical and electrical portions of the accelerometer via the procedure in *Obtaining the Accelerometer Factory Trim (FT) Value* below.

When self-test is activated, the on-board electronics will actuate the appropriate sensor. Please refer to the register 28 for the corresponding bits to activate the self-test. This actuation simulates an external force. The actuated sensor, in turn, will produce a corresponding output signal. The output signal is used to observe the self-test response.

The self-test response (STR) is defined as follows:

SelfTest Response

= Accelerometer Output with Self - Test Enabled - Accelerometer Output with Self - Test Disabled

The self-test response is stored in the sensor data output registers 59 - 64. This self-test-response is used to determine whether the part has passed or failed self-test by finding the change from factory trim of the self-test response as follows:

Change from Factory Trim of the Self-Test Response(%) = $\frac{(STR - FT)}{FT}$

where,

FT = *Factory trim value of selftest response, available via MotionApps software*

This change from factory trim of the self-test response must be within the limits provided in the MPU-9150 Product Specification document for the part to pass self-test. Otherwise, the part is deemed to have failed self-test.

Obtaining the Accelerometer Factory Trim (FT) Value

The following procedure obtains the Factory trim value of the self-test response (FT) mentioned above.



The Factory trim value of the self-test response (FT) is calculated as shown below. FT[Xa], FT[Ya], and FT[Za] refer to the factory trim (FT) values for the accelerometer X, Y, and Z axes, respectively. In the equations below, the factory trim values for the accel should be in decimal format

When performing accelerometer self-test, the full-scale range should be set to $\pm 8g$.

$\begin{cases} FT[Xa] = 4096 * 0.34 * \frac{0.92(\frac{XA_{-}TEST-1}{2^{5}-2})}{0.34} \\ FT[Xa] = 0 \end{cases}$	if XA_TEST \neq 0. if XA_TEST = 0.
$\begin{cases} FT[Ya] = 4096 * 0.34 * \frac{0.92}{0.34} \left(\frac{YA_{TEST-1}}{2^{5}-2} \right) \\ FT[Ya] = 0 \end{cases}$	if YA_TEST \neq 0. if YA_TEST = 0.
$\begin{cases} FT[Za] = 4096 * 0.34 * \frac{0.92}{0.34} \left(\frac{ZA_TEST-1}{2^{5}-2}\right) \\ FT[Za] = 0 \end{cases}$	if ZA_TEST \neq 0. if ZA_TEST = 0.
Parameters:	

XA_TEST	5-bit unsigned value. FT[Xa] is determined by using this value as explained above.
XG_TEST	5-bit unsigned value. FT[Xg] is determined by using this value as explained above.
YA_TEST	5-bit unsigned value. FT[Ya] is determined by using this value as explained above.
YG_TEST	5-bit unsigned value. FT[Yg] is determined by using this value as explained above.
ZA_TEST	5-bit unsigned value. FT[Za] is determined by using this value as explained above.
ZG_TEST	5-bit unsigned value. FT[Zg] is determined by using this value as explained above.

4.2 Register 25 – Sample Rate Divider SMPRT_DIV

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
19	25				SMPLRT	_DIV[7:0]			

Description:

This register specifies the divider from the gyroscope output rate used to generate the Sample Rate for the MPU-9150.

The sensor register output, FIFO output, DMP sampling, Motion detection, Zero Motion detection, and Free Fall detection are all based on the Sample Rate.



The Sample Rate is generated by dividing the gyroscope output rate by *SMPLRT_DIV*:

Sample Rate = Gyroscope Output Rate / (1 + SMPLRT_DIV)

where Gyroscope Output Rate = 8kHz when the DLPF is disabled (*DLPF_CFG* = 0 or 7), and 1kHz when the DLPF is enabled (see Register 26).

<u>Note:</u> The accelerometer output rate is 1kHz. This means that for a Sample Rate greater than 1kHz, the same accelerometer sample may be output to the FIFO, DMP, and sensor registers more than once.

For a diagram of the gyroscope and accelerometer signal paths, see Section 8 of the MPU-9150 Product Specification document.

Parameters:

SMPLRT_DIV

8-bit unsigned value. The Sample Rate is determined by dividing the gyroscope output rate by this value.



4.3 Register 26 – Configuration CONFIG

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
1A	26	-	-	EXT	_SYNC_SET	[2:0]	D	LPF_CFG[2:0]

Description:

This register configures the external Frame Synchronization (FSYNC) pin sampling and the Digital Low Pass Filter (DLPF) setting for both the gyroscopes and accelerometers.

An external signal connected to the FSYNC pin can be sampled by configuring EXT_SYNC_SET.

Signal changes to the FSYNC pin are latched so that short strobes may be captured. The latched FSYNC signal will be sampled at the Sampling Rate, as defined in register 25. After sampling, the latch will reset to the current FSYNC signal state.

The sampled value will be reported in place of the least significant bit in a sensor data register determined by the value of *EXT_SYNC_SET* according to the following table.

EXT_SYNC_SET	FSYNC Bit Location			
0	Input disabled			
1	TEMP_OUT_L[0]			
2	GYRO_XOUT_L[0]			
3	GYRO_YOUT_L[0]			
4	GYRO_ZOUT_L[0]			
5	ACCEL_XOUT_L[0]			
6	ACCEL_YOUT_L[0]			
7	ACCEL_ZOUT_L[0]			

The DLPF is configured by *DLPF_CFG*. The accelerometer and gyroscope are filtered according to the value of *DLPF_CFG* as shown in the table below.

DLPF_CFG	Acceleror (F _s = 1k		Gyroscope			
	Bandwidth (Hz)	Delay (ms)	Bandwidth (Hz)	Delay (ms)	Fs (kHz)	
0	260	0	256	0.98	8	
1	184	2.0	188	1.9	1	
2	94	3.0	98	2.8	1	
3	44	4.9	42	4.8	1	
4	21	8.5	20	8.3	1	
5	10	13.8	10	13.4	1	
6	5	19.0	5	18.6	1	
7	RESER\	/ED	RESERV	/ED	8	

Bit 7 and bit 6 are reserved.

Parameters:

EXT_SYNC_SET DLPF_CFG 3-bit unsigned value. Configures the FSYNC pin sampling.3-bit unsigned value. Configures the DLPF setting.



4.4 Register 27 – Gyroscope Configuration GYRO_CONFIG

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
1B	27	XG_ST	YG_ST	ZG_ST	FS_S	EL[1:0]	-	-	-

Description:

This register is used to trigger gyroscope self-test and configure the gyroscopes' full scale range.

The self-test for each gyroscope axis can be activated by controlling the XG_ST , YG_ST , and ZG_ST bits of this register. Self-test for each axis may be performed independently or all at the same time. Please refer to registers 13 – 16 for further information on gyroscope self-test.

This register is used to configure the gyroscopes' full scale range.

FS_SEL selects the full scale range of the gyroscope outputs according to the following table.

FS_SEL Full Scale Range 0 ± 250 °/s
4 500.8/2
1 ± 500 °/s
2 ± 1000 °/s
3 ± 2000 °/s

Bits 7 through 5 and 2 through 0 are reserved.

Parameters:

FS_SEL 2-bit unsigned value. Selects the full scale range of gyroscopes.



4.5 Register 28 – Accelerometer Configuration ACCEL_CONFIG

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
1C	28	XA_ST	YA_ST	ZA_ST	AFS_S	SEL[1:0]	AC	CEL_HPF[2:0)]-

Description:

This register is used to trigger accelerometer self test and configure the accelerometer full scale range.

The self-test for each accelerometer axis can be activated by controlling the XA_ST , YA_ST , and ZA_ST bits of this register. Self-test for each axis may be performed independently or all at the same time. Please refer to registers 13 – 16 for further information on accelerometer self-test.

This register also configures the Digital High Pass Filter (DHPF).

AFS_SEL selects the full scale range of the accelerometer outputs according to the following table.

AFS_SEL	Full Scale Range	
0	±2g	
1	± 4g	
2	±8g	
3	± 16g	

ACCEL_HPF configures the DHPF available in the path leading to motion detectors (Free Fall, Motion threshold, and Zero Motion). The high pass filter output is not available to the data registers (see Figure in Section 8 of the MPU-9150 Product Specification document).

The high pass filter has three modes:

- Reset: The filter output settles to zero within one sample. This effectively disables the high pass filter. This mode may be toggled to quickly settle the filter.
- On: The high pass filter will pass signals above the cut off frequency.
- Hold: When triggered, the filter holds the present sample. The filter output will be the difference between the input sample and the held sample.

ACCEL_HPF	Filter Mode	Cut-off Frequency		
0	Reset	None		
1	On	5Hz		
2	On	2.5Hz		
3	On	1.25Hz		
4	On	0.63Hz		
7	Hold	None		

XA_ST	When set to 1, the X- Axis accelerometer performs self-test.
YA_ST	When set to 1, the Y- Axis accelerometer performs self-test.
ZA_ST	When set to 1, the Z- Axis accelerometer performs self-test.
ACCEL_FS_SEL	2-bit unsigned value. Selects the full scale range of accelerometers.
ACCEL_HPF	3-bit unsigned value. Selects the Digital High Pass Filter configuration.



4.6 Register 29 – Free Fall Acceleration Threshold FF_THR

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
1D	29				FF_TI	HR[7:0]			

Description:

This register configures the detection threshold for Free Fall event detection. The mg per LSB increment for *FF_THR* can be found in the Electrical Specifications table of the MPU-9150 Product Specification document.

Free Fall is detected when the absolute value of the accelerometer measurements for the three axes are each less than the detection threshold. This condition increments the Free Fall duration counter (Register 30). The Free Fall interrupt is triggered when the Free Fall duration counter reaches the time specified in *FF_DUR* (Register 30).

For more details on the Free Fall detection interrupt, see Section 8.2 of the MPU-9150 Product Specification document as well as Registers 56 and 58 of this document.

Parameters:

FF_THR 8-bit unsigned value specifying the Free Fall detection threshold.

4.7 Register 30 – Free Fall Duration FF DUR

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
1E	30				FF_D	UR[7:0]			

Description:

This register configures the duration counter threshold for Free Fall event detection. The duration counter ticks at 1kHz, therefore FF_DUR has a unit of 1 LSB = 1 ms.

The Free Fall duration counter increments while the absolute value of the accelerometer measurements are each less than the detection threshold (Register 29). The Free Fall interrupt is triggered when the Free Fall duration counter reaches the time specified in this register.

For more details on the Free Fall detection interrupt, see Section 8.2 of the MPU-9150 Product Specification document as well as Registers 56 and 58 of this document.

Parameters:

FF_DUR

8-bit unsigned value. Specifies the duration counter threshold. Unit of LSB = 1ms.



4.8 Register 31 – Motion Detection Threshold MOT_THR

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
1F	31				MOT_T	⁻ HR[7:0]			

Description:

This register configures the detection threshold for Motion interrupt generation. The mg per LSB increment for MOT_THR can be found in the Electrical Specifications table of the MPU-9150 Product Specification document.

Motion is detected when the absolute value of any of the accelerometer measurements exceeds this Motion detection threshold.

The Motion interrupt will indicate the axis and polarity of detected motion in MOT_DETECT _STATUS (Register 97).

For more details on the Motion detection interrupt, see the MPU-9150 Product Specification document as well as Registers 56 and 58 of this document.

This register configures the detection threshold for Motion interrupt generation. The mg per LSB increment for *MOT_THR* can be found in the Electrical Specifications table of the MPU-9150 Product Specification document.

Motion is detected when the absolute value of any of the accelerometer measurements exceeds this Motion detection threshold. This condition increments the Motion detection duration counter (Register 32). The Motion detection interrupt is triggered when the Motion Detection counter reaches the time count specified in *MOT_DUR* (Register 32).

The Motion interrupt will indicate the axis and polarity of detected motion in MOT_DETECT _STATUS (Register 97).

For more details on the Motion detection interrupt, see Section 8.3 of the MPU-9150 Product Specification document as well as Registers 56 and 58 of this document.

Parameters:

MOT_THR 8-bit unsigned value. Specifies the Motion detection threshold.

4.9 Register 32 – Motion Detection Duration MOT_DUR

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
20	32				MOT_D	DUR[7:0]			

Description:

This register configures the duration counter threshold for Motion interrupt generation. The duration counter ticks at 1 kHz, therefore MOT_DUR has a unit of 1 LSB = 1 ms.



The Motion detection duration counter increments when the absolute value of any of the accelerometer measurements exceeds the Motion detection threshold (Register 31). The Motion detection interrupt is triggered when the Motion detection counter reaches the time count specified in this register.

For more details on the Motion detection interrupt, see Section 8.3 of the MPU-9150 Product Specification document.

Parameters:

MOT_DUR 8-bit unsigned value. Specifies the duration counter threshold. Unit of 1 LSB = 1ms.



4.10 Register 33 – Zero Motion Detection Threshold ZRMOT_THR

Type: Read/Write

Registe (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
21	33				ZRMOT_	_THR[7:0]			

Description:

This register configures the detection threshold for Zero Motion interrupt generation. The mg per LSB increment for *ZRMOT_THR* can be found in the Electrical Specifications table of the MPU-9150 Product Specification document.

Zero Motion is detected when the absolute value of the accelerometer measurements for the 3 axes are each less than the detection threshold. This condition increments the Zero Motion duration counter (Register 34). The Zero Motion interrupt is triggered when the Zero Motion duration counter reaches the time count specified in *ZRMOT_DUR* (Register 34).

Unlike Free Fall or Motion detection, Zero Motion detection triggers an interrupt both when Zero Motion is first detected and when Zero Motion is no longer detected.

When a zero motion event is detected, a Zero Motion Status will be indicated in the MOT_DETECT_STATUS register (Register 97). When a motion-to-zero-motion condition is detected, the status bit is set to 1. When a zero-motion-to-motion condition is detected, the status bit is set to 0.

For more details on the Zero Motion detection interrupt, see Section 8.4 of the MPU-9150 Product Specification document as well as Registers 56 and 58 of this document.

Parameters:

ZRMOT_THR 8-bit unsigned value. Specifies the Zero Motion detection threshold.

4.11 Register 34 – Zero Motion Detection Duration ZRMOT_DUR

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
22	34				ZRMOT_	_DUR[7:0]			

Description:

This register configures the duration counter threshold for Zero Motion interrupt generation. The duration counter ticks at 16 Hz, therefore $ZRMOT_DUR$ has a unit of 1 LSB = 64 ms.

The Zero Motion duration counter increments while the absolute value of the accelerometer measurements are each less than the detection threshold (Register 33). The Zero Motion interrupt is triggered when the Zero Motion duration counter reaches the time count specified in this register.

For more details on the Zero Motion detection interrupt, see Section 8.4 of the MPU-9150 Product Specification document, as well as Registers 56 and 58 of this document.

Parameters:

ZRMOT_DUR

8-bit unsigned value. Specifies the duration counter threshold. Unit of 1 LSB = 64 ms.



4.12 Register 35 – FIFO Enable FIFO_EN

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
23	35	TEMP_ FIFO_EN	XG_ FIFO_EN	YG_ FIFO_EN	ZG_ FIFO_EN	ACCEL _FIFO_EN	SLV2 _FIFO_EN	SLV1 _FIFO_EN	SLV0 _FIFO_EN

Description:

This register determines which sensor measurements are loaded into the FIFO buffer.

Data stored inside the sensor data registers (Registers 59 to 96) will be loaded into the FIFO buffer if a sensor's respective FIFO_EN bit is set to 1 in this register.

When a sensor's FIFO_EN bit is enabled in this register, data from the sensor data registers will be loaded into the FIFO buffer. The sensors are sampled at the Sample Rate as defined in Register 25. For further information regarding sensor data registers, please refer to Registers 59 to 96

When an external Slave's corresponding FIFO_EN bit (*SLVx_FIFO_EN*, where x=0, 1, or 2) is set to 1, the data stored in its corresponding data registers (EXT_SENS_DATA registers, Registers 73 to 96) will be written into the FIFO buffer at the Sample Rate. EXT_SENS_DATA register association with I²C Slaves is determined by the I2C_SLVx_CTRL registers (where x=0, 1, or 2; Registers 39, 42, and 45). For information regarding EXT_SENS_DATA registers, please refer to Registers 73 to 96.

Note that the corresponding FIFO_EN bit (*SLV3_FIFO_EN*) is found in I2C_MST_CTRL (Register 36). Also note that Slave 4 behaves in a different manner compared to Slaves 0-3. Please refer to Registers 49 to 53 for further information regarding Slave 4 usage.

Parameters:

TEMP_FIFO_EN	When set to 1, this bit enables TEMP_OUT_H and TEMP_OUT_L (Registers 65 and 66) to be written into the FIFO buffer.
XG_ FIFO_EN	When set to 1, this bit enables GYRO_XOUT_H and GYRO_XOUT_L (Registers 67 and 68) to be written into the FIFO buffer.
YG_ FIFO_EN	When set to 1, this bit enables GYRO_YOUT_H and GYRO_YOUT_L (Registers 69 and 70) to be written into the FIFO buffer.
ZG_ FIFO_EN	When set to 1, this bit enables GYRO_ZOUT_H and GYRO_ZOUT_L (Registers 71 and 72) to be written into the FIFO buffer.
ACCEL_ FIFO_EN	When set to 1, this bit enables ACCEL_XOUT_H, ACCEL_XOUT_L, ACCEL_YOUT_H, ACCEL_YOUT_L, ACCEL_ZOUT_H, and ACCEL_ZOUT_L (Registers 59 to 64) to be written into the FIFO buffer.
SLV2_ FIFO_EN	When set to 1, this bit enables EXT_SENS_DATA registers (Registers 73 to 96) associated with Slave 2 to be written into the FIFO buffer.
SLV1_ FIFO_EN	When set to 1, this bit enables EXT_SENS_DATA registers (Registers 73 to 96) associated with Slave 1 to be written into the FIFO buffer.
SLV0_ FIFO_EN	When set to 1, this bit enables EXT_SENS_DATA registers (Registers 73 to 96) associated with Slave 0 to be written into the FIFO buffer.

<u>Note</u>: For further information regarding the association of EXT_SENS_DATA registers to particular slave devices, please refer to Registers 73 to 96.



4.13 Register 36 – I²C Master Control I2C_MST_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
24	36	MULT _MST_EN	WAIT _FOR_ES	SLV_3 _FIFO_EN	l2C_MST _P_NSR		I2C_MST	_CLK[3:0]	

Description:

This register configures the auxiliary I²C bus for single-master or multi-master control. In addition, the register is used to delay the Data Ready interrupt, and also enables the writing of Slave 3 data into the FIFO buffer. The register also configures the auxiliary I²C Master's transition from one slave read to the next, as well as the MPU-9150's 8MHz internal clock.

Multi-master capability allows multiple I^2C masters to operate on the same bus. In circuits where multi-master capability is required, set *MULT_MST_EN* to 1. This will increase current drawn by approximately $30\mu A$.

In circuits where multi-master capability is required, the state of the I^2C bus must always be monitored by each separate I^2C Master. Before an I^2C Master can assume arbitration of the bus, it must first confirm that no other I^2C Master has arbitration of the bus. When *MULT_MST_EN* is set to 1, the MPU-9150's bus arbitration detection logic is turned on, enabling it to detect when the bus is available.

When the *WAIT_FOR_ES* bit is set to 1, the Data Ready interrupt will be delayed until External Sensor data from the Slave Devices are loaded into the EXT_SENS_DATA registers. This is used to ensure that both the internal sensor data (i.e. from gyro and accel) and external sensor data have been loaded to their respective data registers (i.e. the data is synced) when the Data Ready interrupt is triggered.

When the Slave 3 FIFO enable bit (*SLV_3_FIFO_EN*) is set to 1, Slave 3 sensor measurement data will be loaded into the FIFO buffer each time. EXT_SENS_DATA register association with I²C Slaves is determined by I2C_SLV3_CTRL (Register 48).

For further information regarding EXT_SENS_DATA registers, please refer to Registers 73 to 96.

The corresponding FIFO_EN bits for Slave 0, Slave 1, and Slave 2 can be found in Register 35.

The $I2C_MST_P_NSR$ bit configures the I^2C Master's transition from one slave read to the next slave read. If the bit equals 0, there will be a restart between reads. If the bit equals 1, there will be a stop followed by a start of the following read. When a write transaction follows a read transaction, the stop followed by a start of the successive write will be always used.



 $I2C_MST_CLK$ is a 4 bit unsigned value which configures a divider on the MPU-9150 internal 8MHz clock. It sets the I²C master clock speed according to the following table:

I2C_MST_CLK	I ² C Master Clock Speed	8MHz Clock Divider
0	348 kHz	23
1	333 kHz	24
2	320 kHz	25
3	308 kHz	26
4	296 kHz	27
5	286 kHz	28
6	276 kHz	29
7	267 kHz	30
8	258 kHz	31
9	500 kHz	16
10	471 kHz	17
11	444 kHz	18
12	421 kHz	19
13	400 kHz	20
14	381 kHz	21
15	364 kHz	22

Parameters:

MUL_MST_EN When set to 1, this bit enables multi-master capability.

WAIT_FOR_ES When set to 1, this bit delays the Data Ready interrupt until External Sensor data from the Slave devices have been loaded into the EXT_SENS_DATA registers.

- SLV3_FIFO_EN When set to 1, this bit enables EXT_SENS_DATA registers associated with Slave 3 to be written into the FIFO. The corresponding bits for Slaves 0-2 can be found in Register 35.
- I2C_MST_P_NSR
 Controls the I²C Master's transition from one slave read to the next slave read.
 When this bit equals 0, there is a restart between reads.
 When this bit equals 1, there is a stop and start marking the beginning of the next read.
 When a write follows a read, a stop and start is always enforced.

I2C_MST_CLK 4 bit unsigned value. Configures the I²C master clock speed divider.

<u>Note</u>: For further information regarding the association of EXT_SENS_DATA registers to particular slave devices, please refer to Registers 73 to 96.



4.14 Registers 37 to 39 – I²C Slave 0 Control I2C_SLV0_ADDR, I2C_SLV0_REG, and I2C_SLV0_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
25	37	I2C_SLV0 _RW			12	C_SLV0_ADDR	[6:0]		
26	38				I2C_SLV0	D_REG[7:0]			
27	39	I2C_SLV0 _EN	I2C_SLV0 _BYTE _SW	I2C_SLV0_ REG_DIS	I2C_SLV 0_GRP		I2C_SLV0	_LEN[3:0]	

Description:

These registers configure the data transfer sequence for Slave 0. Slaves 1, 2, and 3 also behave in a similar manner to Slave 0. However, Slave 4's characteristics differ greatly from those of Slaves 0-3. For further information regarding Slave 4, please refer to registers 49 to 53.

 I^2C slave data transactions between the MPU-9150 and Slave 0 are set as either read or write operations by the *I*2*C*_*SLV0_RW* bit. When this bit is 1, the transfer is a read operation. When the bit is 0, the transfer is a write operation.

 $I2C_SLV0_ADDR$ is used to specify the I²C slave address of Slave 0.

Data transfer starts at an internal register within Slave 0. This address of this register is specified by *I2C_SLV0_REG*.

The number of bytes transferred is specified by $I2C_SLV0_LEN$. When more than 1 byte is transferred ($I2C_SLV0_LEN > 1$), data is read from (written to) sequential addresses starting from $I2C_SLV0_REG$.

In read mode, the result of the read is placed in the lowest available EXT_SENS_DATA register. For further information regarding the allocation of read results, please refer to the EXT_SENS_DATA register description (Registers 73 – 96).

In write mode, the contents of I2C_SLV0_DO (Register 99) will be written to the slave device.

 $l2C_SLV0_EN$ enables Slave 0 for l^2C data transaction. A data transaction is performed only if more than zero bytes are to be transferred ($l2C_SLV0_LEN > 0$) between an enabled slave device ($l2C_SLV0_EN = 1$).

I2C_SLV0_BYTE_SW configures byte swapping of word pairs. When byte swapping is enabled, the high and low bytes of a word pair are swapped. Please refer to *I2C_SLV0_GRP* for the pairing convention of the word pairs. When this bit is cleared to 0, bytes transferred to and from Slave 0 will be written to EXT_SENS_DATA registers in the order they were transferred.

When *I2C_SLV0_REG_DIS* is set to 1, the transaction will read or write data only. When cleared to 0, the transaction will write a register address prior to reading or writing data. This bit should equal 0 when specifying the register address within the Slave device to/from which the ensuing data transaction will take place.



I2C_SLV0_GRP specifies the grouping order of word pairs received from registers. When cleared to 0, bytes from register addresses 0 and 1, 2 and 3, etc (even, then odd register addresses) are paired to form a word. When set to 1, bytes from register addresses are paired 1 and 2, 3 and 4, etc. (odd, then even register addresses) are paired to form a word.

I²C data transactions are performed at the Sample Rate, as defined in Register 25. The user is responsible for ensuring that I²C data transactions to and from each enabled Slave can be completed within a single period of the Sample Rate.

The I²C slave access rate can be reduced relative to the Sample Rate. This reduced access rate is determined by *I*2*C_MST_DLY* (Register 52). Whether a slave's access rate is reduced relative to the Sample Rate is determined by I2*C_MST_DELAY_CTRL* (Register 103).

The processing order for the slaves is fixed. The sequence followed for processing the slaves is Slave 0, Slave 1, Slave 2, Slave 3 and Slave 4. If a particular Slave is disabled it will be skipped.

Each slave can either be accessed at the sample rate or at a reduced sample rate. In a case where some slaves are accessed at the Sample Rate and some slaves are accessed at the reduced rate, the sequence of accessing the slaves (Slave 0 to Slave 4) is still followed. However, the reduced rate slaves will be skipped if their access rate dictates that they should not be accessed during that particular cycle. For further information regarding the reduced access rate, please refer to Register 52. Whether a slave is accessed at the Sample Rate or at the reduced rate is determined by the Delay Enable bits in Register 103.

I2C_SLV0_RW	When set to 1, this bit configures the data transfer as a read operation. When cleared to 0, this bit configures the data transfer as a write operation. 7-bit I^2C address of Slave 0.
I2C_SLV0_ADDR	8-bit address of the Slave 0 register to/from which data transfer starts.
I2C_SLV0_EN	When set to 1, this bit enables Slave 0 for data transfer operations. When cleared to 0, this bit disables Slave 0 from data transfer operations.
I2C_SLV0_BYTE_SW	When set to 1, this bit enables byte swapping. When byte swapping is enabled, the high and low bytes of a word pair are swapped. Please refer to <i>I2C_SLV0_GRP</i> for the pairing convention of the word pairs.
10,	When cleared to 0, bytes transferred to and from Slave 0 will be written to EXT_SENS_DATA registers in the order they were transferred.
I2C_SLV0_REG_DIS	When set to 1, the transaction will read or write data only. When cleared to 0, the transaction will write a register address prior to reading or writing data.
I2C_SLV0_GRP	1-bit value specifying the grouping order of word pairs received from registers. When cleared to 0, bytes from register addresses 0 and 1, 2 and 3, etc (even, then odd register addresses) are paired to form a word. When set to 1, bytes from register addresses are paired 1 and 2, 3 and 4, etc. (odd, then even register addresses) are paired to form a word.
I2C_SLV0_LEN	4-bit unsigned value. Specifies the number of bytes transferred to and from Slave 0.
	Clearing this bit to 0 is equivalent to disabling the register by writing 0 to I2C SLV0 EN.



Byte Swapping Example

The following example demonstrates byte swapping for $l2C_SLV0_BYTE_SW = 1$, $l2C_SLV0_GRP = 0$, $l2C_SLV0_REG = 0x01$, and $l2C_SLV0_LEN = 0x4$:

- The first byte, read from Slave 0 register 0x01, will be stored at EXT_SENS_DATA_00. Because *I2C_SLV0_GRP* = 0, bytes from even, then odd register addresses will be paired together as word pairs. Since the read operation started from an odd register address instead of an even address, only one byte is read.
- 2. The second and third bytes will be swapped, since *I2C_SLV0_BYTE_SW* = 1 and *I2C_SLV0_REG[0]* = 1. The data read from 0x02 will be stored at EXT_SENS_DATA_02, and the data read from 0x03 will be stored at EXT_SENS_DATA_01.
- 3. The last byte, read from address 0x04, will be stored at EXT_SENS_DATA_03. Because there is only one byte remaining in the read operation, byte swapping will not occur.

Slave Access Example

Slave 0 is accessed at the Sample Rate, while Slave 1 is accessed at half the Sample Rate. The other slaves are disabled. In the first cycle, both Slave 0 and Slave 1 will be accessed. However, in the second cycle, only Slave 0 will be accessed. In the third cycle, both Slave 0 and Slave 1 will be accessed. In the fourth cycle, only Slave 0 will be accessed. This pattern continues.



4.15 Registers 40 to 42 – I²C Slave 1 Control I2C_SLV1_ADDR, I2C_SLV1_REG, and I2C_SLV1_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
28	40	I2C_SLV1 _RW			12	C_SLV1_ADDR	[6:0]		
29	41				I2C_SLV1	I_REG[7:0]			
2A	42	I2C_SLV1 _EN	I2C_SLV1 _BYTE _SW	I2C_SLV1_ REG_DIS	I2C_SLV 1_GRP		I2C_SLV1	_LEN[3:0]	

Description:

These registers describe the data transfer sequence for Slave 1. Their functions correspond to those described for the Slave 0 registers (Registers 37 to 39).

4.16 Registers 43 to 45 – I²C Slave 2 Control I2C_SLV2_ADDR, I2C_SLV2_REG, and I2C_SLV2_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
2B	43	I2C_SLV2 _RW			12	C_SLV2_ADDR	[6:0]		
2C	44				I2C_SLV2	2_REG[7:0]			
2D	45	I2C_SLV2 _EN	I2C_SLV2 _BYTE _SW	I2C_SLV2_ REG_DIS	I2C_SLV 2_GRP		I2C_SLV2	_LEN[3:0]	

Description:

These registers describe the data transfer sequence for Slave 2. Their functions correspond to those described for the Slave 0 registers (Registers 37 to 39).

4.17 Registers 46 to 48 – I²C Slave 3 Control I2C_SLV3_ADDR, I2C_SLV3_REG, and I2C_SLV3_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
2E	46	I2C_SLV3 _RW			12	C_SLV3_ADDR	[6:0]		
2F	47				I2C_SLV3	3_REG[7:0]			
30	48	I2C_SLV3 _EN	I2C_SLV3 _BYTE _SW	I2C_SLV3_ REG_DIS	I2C_SLV 3_GRP		I2C_SLV3	_LEN[3:0]	

Description:

These registers describe the data transfer sequence for Slave 3. Their functions correspond to those described for the Slave 0 registers (Registers 37 to 39).



4.18 Registers 49 to 53 – I²C Slave 4 Control

I2C_SLV4_ADDR, I2C_SLV4_REG, I2C_SLV4_DO, I2C_SLV4_CTRL, and I2C_SLV4_DI

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	
31	49	I2C_SLV4 _RW		I2C_SLV4_ADDR[6:0]						
32	50			I2C_SLV4_REG[7:0]						
33	51				I2C_SLV	'4_DO[7:0]				
34	52	I2C_SLV4_ EN	I2C_SLV4 _INT_EN	I2C_SLV4 _REG_DIS		12	2C_MST_DLY[4	:0]		
35	53			I2C_SLV4_DI[7:0]						

Description:

These registers describe the data transfer sequence for Slave 4. The characteristics of Slave 4 differ greatly from those of Slaves 0-3. For further information regarding the characteristics of Slaves 0-3, please refer to Registers 37 to 48.

 I^2C slave data transactions between the MPU-9150 and Slave 4 are set as either read or write operations by the $I2C_SLV4_RW$ bit. When this bit is 1, the transfer is a read operation. When the bit is 0, the transfer is a write operation.

I2C_SLV4_ADDR is used to specify the I²C slave address of Slave 4.

Data transfer starts at an internal register within Slave 4. This register address is specified by *I2C_SLV4_REG*.

In read mode, the result of the read will be available in *I*2C_SLV4_DI. In write mode, the contents of *I*2C_SLV4_DO will be written into the slave device.

A data transaction is performed only if the *I2C_SLV4_EN* bit is set to 1. The data transaction should be enabled once its parameters are configured in the _ADDR and _REG registers. For write, the _DO register is also required. *I2C_SLV4_EN* will be cleared after the transaction is performed once.

An interrupt is triggered at the completion of a Slave 4 data transaction if the interrupt is enabled. The status of this interrupt can be observed in Register 54.

When *I2C_SLV4_REG_DIS* is set to 1, the transaction will read or write data instead of writing a register address. This bit should equal 0 when specifying the register address within the Slave device to/from which the ensuing data transaction will take place.

I2C_MST_DLY configures the reduced access rate of I²C slaves relative to the Sample Rate. When a slave's access rate is decreased relative to the Sample Rate, the slave is accessed every

1 / (1 + *I*2*C_MST_DLY*) samples

This base Sample Rate in turn is determined by *SMPLRT_DIV* (register 25) and *DLPF_CFG* (register 26). Whether a slave's access rate is reduced relative to the Sample Rate is determined by I2C_MST_DELAY_CTRL (register 103).

For further information regarding the Sample Rate, please refer to register 25.

Slave 4 transactions are performed after Slave 0, 1, 2 and 3 transactions have been completed. Thus the maximum rate for Slave 4 transactions is determined by the Sample Rate as defined in Register 25.



Parameters:

I2C_SLV4_RW	When set to 1, this bit configures the data transfer as a read operation. When cleared to 0, this bit configures the data transfer as a write operation.					
I2C_SLV4_ADDR	7-bit I ² C address for Slave 4.					
I2C_SLV4_REG	8-bit address of the Slave 4 register to/from which data transfer starts.					
I2C_SLV4_DO	This register stores the data to be written into the Slave 4. If <i>I2C_SLV4_RW</i> is set 1 (set to read), this register has no effect.					
I2C_SLV4_EN	When set to 1, this bit enables Slave 4 for data transfer operations.					
	When cleared to 0, this bit disables Slave 4 from data transfer operations.					
I2C_SLV4_INT_EN	When set to 1, this bit enables the generation of an interrupt signal upon completion of a Slave 4 transaction.					
	When cleared to 0, this bit disables the generation of an interrupt signal upon completion of a Slave 4 transaction.					
	The interrupt status can be observed in Register 54.					
I2C_SLV4_REG_DIS	When set to 1, the transaction will read or write data. When cleared to 0, the transaction will read or write a register address.					
I2C_MST_DLY	Configures the decreased access rate of slave devices relative to the Sample Rate.					
I2C_SLV4_DI	This register stores the data read from Slave 4.					
	This field is populated after a read transaction.					

28 of 60



4.19 Register 54 – I²C Master Status I2C_MST_STATUS

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
36	54	PASS_ THROUGH	I2C_SLV4 _DONE	I2C_LOST _ARB	I2C_SLV4 _NACK	I2C_SLV3 _NACK	I2C_SLV2 _NACK	I2C_SLV1 _NACK	I2C_SLV0 _NACK

Description:

This register shows the status of the interrupt generating signals in the I²C Master within the MPU-9150. This register also communicates the status of the FSYNC interrupt to the host processor.

Reading this register will clear all the status bits in the register.

PASS_THROUGH	This bit reflects the status of the FSYNC interrupt from an external device into the MPU-9150. This is used as a way to pass an external interrupt through the MPU-9150 to the host application processor. When set to 1, this bit will cause an interrupt if <i>FSYNC_INT_EN</i> is asserted in INT_PIN_CFG (Register 55).
I2C_SLV4_DONE	Automatically sets to 1 when a Slave 4 transaction has completed. This triggers an interrupt if the <i>I2C_MST_INT_EN</i> bit in the INT_ENABLE register (Register 56) is asserted and if the <i>SLV_4_DONE_INT</i> bit is asserted in the I2C_SLV4_CTRL register (Register 52).
I2C_LOST_ARB	This bit automatically sets to 1 when the I^2C Master has lost arbitration of the auxiliary I^2C bus (an error condition). This triggers an interrupt if the $I2C_MST_INT_EN$ bit in the INT_ENABLE register (Register 56) is asserted.
I2C_SLV4_NACK	This bit automatically sets to 1 when the I ² C Master receives a NACK in a transaction with Slave 4. This triggers an interrupt if the <i>I</i> 2C_MST_INT_EN bit in the INT_ENABLE register (Register 56) is asserted.
I2C_SLV3_NACK	This bit automatically sets to 1 when the I ² C Master receives a NACK in a transaction with Slave 3. This triggers an interrupt if the <i>I</i> 2C_MST_INT_EN bit in the INT_ENABLE register (Register 56) is asserted.
I2C_SLV2_NACK	This bit automatically sets to 1 when the I ² C Master receives a NACK in a transaction with Slave 2. This triggers an interrupt if the <i>I</i> 2C_MST_INT_EN bit in the INT_ENABLE register (Register 56) is asserted.
I2C_SLV1_NACK	This bit automatically sets to 1 when the I ² C Master receives a NACK in a transaction with Slave 1. This triggers an interrupt if the <i>I</i> 2C_MST_INT_EN bit in the INT_ENABLE register (Register 56) is asserted.
I2C_SLV0_NACK	This bit automatically sets to 1 when the I ² C Master receives a NACK in a transaction with Slave 0. This triggers an interrupt if the I2C_MST_INT_EN bit in the INT_ENABLE register (Register 56) is asserted.



4.20 Register 55 – INT Pin / Bypass Enable Configuration INT_PIN_CFG

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
37	55	INT_LEVEL	INT_OPEN	LATCH _INT_EN	INT_RD _CLEAR	FSYNC_ INT_LEVEL	FSYNC_ INT_EN	I2C _BYPASS _EN	CLKOUT _EN

Description:

This register configures the behavior of the interrupt signals at the INT pins. This register is also used to enable the FSYNC Pin to be used as an interrupt to the host application processor, as well as to enable Bypass Mode on the I^2C Master. This bit also enables the clock output.

FSYNC_INT_EN enables the FSYNC pin to be used as an interrupt to the host application processor. A transition to the active level specified in *FSYNC_INT_LEVEL* will trigger an interrupt. The status of this interrupt is read from the *PASS_THROUGH* bit in the I²C Master Status Register (Register 54).

When $I2C_BYPASS_EN$ is equal to 1 and $I2C_MST_EN$ (Register 106 bit[5]) is equal to 0, the host application processor will be able to directly access the auxiliary I²C bus of the MPU-9150. When this bit is equal to 0, the host application processor will not be able to directly access the auxiliary I²C bus of the MPU-9150 regardless of the state of $I2C_MST_EN$.

For further information regarding Bypass Mode, please refer to Section 7.12 and 7.14 of the MPU-9150 Product Specification document.

INT_LEVEL	When this bit is equal to 0, the logic level for the INT pin is active high. When this bit is equal to 1, the logic level for the INT pin is active low.
INT_OPEN	When this bit is equal to 0, the INT pin is configured as push-pull. When this bit is equal to 1, the INT pin is configured as open drain.
LATCH_INT_EN	When this bit is equal to 0, the INT pin emits a 50us long pulse. When this bit is equal to 1, the INT pin is held high until the interrupt is cleared.
INT_RD_CLEAR	When this bit is equal to 0, interrupt status bits are cleared only by reading INT_STATUS (Register 58)
~	When this bit is equal to 1, interrupt status bits are cleared on any read operation.
FSYNC_INT_LEVEL	When this bit is equal to 0, the logic level for the FSYNC pin (when used as an interrupt to the host processor) is active high. When this bit is equal to 1, the logic level for the FSYNC pin (when used as an interrupt to the host processor) is active low.
FSYNC_INT_EN	When equal to 0, this bit disables the FSYNC pin from causing an interrupt to the host processor.
	When equal to 1, this bit enables the FSYNC pin to be used as an interrupt to the host processor.



I2C_BYPASS_EN When this bit is equal to 1 and *I2C_MST_EN* (Register 106 bit[5]) is equal to 0, the host application processor will be able to directly access the auxiliary I²C bus of the MPU-9150.

When this bit is equal to 0, the host application processor will not be able to directly access the auxiliary I^2C bus of the MPU-9150 regardless of the state of $I2C_MST_EN$ (Register 106 bit[5]).

CLKOUT_EN When this bit is equal to 1, a reference clock output is provided at the CLKOUT pin. When this bit is equal to 0, the clock output is disabled.

For further information regarding CLKOUT, please refer to the MPU-9150 Product Specification document.



4.21 Register 56 – Interrupt Enable INT_ENABLE

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
38	56	FF_EN	MOT_EN	ZMOT_EN	FIFO _OFLOW _EN	I2C_MST _INT_EN	-	-	DATA _RDY_EN

Description:

This register enables interrupt generation by interrupt sources.

For information regarding Free Fall detection, Motion detection, and Zero Motion detection, please refer to Registers 29 to 34

For information regarding the interrupt status for of each interrupt generation source, please refer to Register 58. Further information regarding I^2C Master interrupt generation can be found in Register 54.

Bits 2 and 1 are reserved.

FF_EN	When set to 1, this bit enables Free Fall detection to generate an interrupt.
MOT_EN	When set to 1, this bit enables Motion detection to generate an interrupt.
ZMOT_EN	When set to 1, this bit enables Zero Motion detection to generate an interrupt.
FIFO_OFLOW_EN	When set to 1, this bit enables a FIFO buffer overflow to generate an interrupt.
I2C_MST_INT_EN	When set to 1, this bit enables any of the I ² C Master interrupt sources to generate an interrupt.
DATA_RDY_EN	When set to 1, this bit enables the Data Ready interrupt, which occurs each time a write operation to all of the sensor registers has been completed.



4.22 Register 58 – Interrupt Status INT_STATUS

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
ЗA	58	FF_INT	MOT_INT	ZMOT _INT	FIFO _OFLOW _INT	I2C_MST _INT	-	-	DATA _RDY_INT

Description:

This register shows the interrupt status of each interrupt generation source. Each bit will clear after the register is read.

For information regarding the corresponding interrupt enable bits, please refer to Register 56.

For a list of I²C Master interrupts, please refer to Register 54.

Bits 2 and 1 are reserved.

FF_INT	This bit automatically sets to 1 when a Free Fall interrupt has been generated.
	The bit clears to 0 after the register has been read.
MOT_INT	This bit automatically sets to 1 when a Motion Detection interrupt has been generated.
	The bit clears to 0 after the register has been read.
ZMOT_INT	This bit automatically sets to 1 when a Zero Motion Detection interrupt has been generated.
	The bit clears to 0 after the register has been read.
FIFO_OFLOW_INT	This bit automatically sets to 1 when a FIFO buffer overflow interrupt has been generated.
	The bit clears to 0 after the register has been read.
I2C_MST_INT	This bit automatically sets to 1 when an I^2C Master interrupt has been generated. For a list of I^2C Master interrupts, please refer to Register 54.
	The bit clears to 0 after the register has been read.
DATA_RDY_INT	This bit automatically sets to 1 when a Data Ready interrupt is generated.
\mathbf{O}	The bit clears to 0 after the register has been read.



4.23 Registers 59 to 64 – Accelerometer Measurements ACCEL_XOUT_H, ACCEL_XOUT_L, ACCEL_YOUT_H, ACCEL_YOUT_L, ACCEL_ZOUT_H, and ACCEL_ZOUT_L

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0	
3B	59		ACCEL_XOUT[15:8]							
3C	60		ACCEL_XOUT[7:0]							
3D	61			AC	CEL_YOUT[15:8]				
3E	62			AC	CEL_YOUT[7:0]				
3F	63		ACCEL_ZOUT[15:8]							
40	64			AC	CEL_ZOUT[7	7:0]				

Description:

These registers store the most recent accelerometer measurements.

Accelerometer measurements are written to these registers at the Sample Rate as defined in Register 25.

The accelerometer measurement registers, along with the temperature measurement registers, gyroscope measurement registers, and external sensor data registers, are composed of two sets of registers: an internal register set and a user-facing read register set.

The data within the accelerometer sensors' internal register set is always updated at the Sample Rate. Meanwhile, the user-facing read register set duplicates the internal register set's data values whenever the serial interface is idle. This guarantees that a burst read of sensor registers will read measurements from the same sampling instant. Note that if burst reads are not used, the user is responsible for ensuring a set of single byte reads correspond to a single sampling instant by checking the Data Ready interrupt.

Each 16-bit accelerometer measurement has a full scale defined in ACCEL_FS (Register 28). For each full scale setting, the accelerometers' sensitivity per LSB in ACCEL_xOUT is shown in the table below.

AFS_SEL	Full Scale Range	LSB Sensitivity
0	±2g	16384 LSB/mg
1	±4g	8192 LSB/mg
2	±8g	4096 LSB/mg
3	±16g	2048 LSB/mg

ACCEL_XOUT	16-bit 2's complement value.
	Stores the most recent X axis accelerometer measurement.
ACCEL_YOUT	16-bit 2's complement value.
	Stores the most recent Y axis accelerometer measurement.
ACCEL_ZOUT	16-bit 2's complement value.
	Stores the most recent Z axis accelerometer measurement.



4.24 Registers 65 and 66 – Temperature Measurement TEMP_OUT_H and TEMP_OUT_L

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
41	65	TEMP_OUT[15:8]							
42	66	TEMP_OUT[7:0]							

Description:

These registers store the most recent temperature sensor measurement.

Temperature measurements are written to these registers at the Sample Rate as defined in Register 25.

These temperature measurement registers, along with the accelerometer measurement registers, gyroscope measurement registers, and external sensor data registers, are composed of two sets of registers: an internal register set and a user-facing read register set.

The data within the temperature sensor's internal register set is always updated at the Sample Rate. Meanwhile, the user-facing read register set duplicates the internal register set's data values whenever the serial interface is idle. This guarantees that a burst read of sensor registers will read measurements from the same sampling instant. Note that if burst reads are not used, the user is responsible for ensuring a set of single byte reads correspond to a single sampling instant by checking the Data Ready interrupt.

The scale factor and offset for the temperature sensor are found in the Electrical Specifications table in the MPU-9150 Product Specification document.

The temperature in degrees C for a given register value may be computed as:

Temperature in degrees C = (TEMP_OUT Register Value as a signed quantity)/340 + 35

Please note that the math in the above equation is in decimal.

Parameters:

TEMP_OUT 16-bit signed value.

Stores the most recent temperature sensor measurement.



4.25 Registers 67 to 72 – Gyroscope Measurements GYRO_XOUT_H, GYRO_XOUT_L, GYRO_YOUT_H, GYRO_YOUT_L, GYRO_ZOUT_H, and GYRO_ZOUT_L

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
43	67	GYRO_XOUT[15:8]							
44	68	GYRO_XOUT[7:0]							
45	69	GYRO_YOUT[15:8]							
46	70	GYRO_YOUT[7:0]							
47	71	GYRO_ZOUT[15:8]							
48	72	GYRO_ZOUT[7:0]							

Description:

These registers store the most recent gyroscope measurements.

Gyroscope measurements are written to these registers at the Sample Rate as defined in Register 25.

These gyroscope measurement registers, along with the accelerometer measurement registers, temperature measurement registers, and external sensor data registers, are composed of two sets of registers: an internal register set and a user-facing read register set.

The data within the gyroscope sensors' internal register set is always updated at the Sample Rate. Meanwhile, the user-facing read register set duplicates the internal register set's data values whenever the serial interface is idle. This guarantees that a burst read of sensor registers will read measurements from the same sampling instant. Note that if burst reads are not used, the user is responsible for ensuring a set of single byte reads correspond to a single sampling instant by checking the Data Ready interrupt.

Each 16-bit gyroscope measurement has a full scale defined in *FS_SEL* (Register 27). For each full scale setting, the gyroscopes' sensitivity per LSB in *GYRO_xOUT* is shown in the table below:

FS_SEL	Full Scale Range	LSB Sensitivity
0	± 250 °/s	131 LSB/°/s
1	± 500 °/s	65.5 LSB/°/s
2	± 1000 °/s	32.8 LSB/°/s
3	± 2000 °/s	16.4 LSB/°/s

GYRO_XOUT	16-bit 2's complement value.		
	Stores the most recent X axis gyroscope measurement.		
GYRO_YOUT	16-bit 2's complement value.		
	Stores the most recent Y axis gyroscope measurement.		
GYRO_ZOUT	16-bit 2's complement value.		
	Stores the most recent Z axis gyroscope measurement.		



4.26 Registers 73 to 96 – External Sensor Data EXT_SENS_DATA_00 through EXT_SENS_DATA_23

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
49	73				EXT_SENS_	DATA_00[7:0]]		
4A	74				EXT_SENS_	DATA_01[7:0]]		
4B	75				EXT_SENS_	DATA_02[7:0]]		
4C	76				EXT_SENS_	DATA_03[7:0]]		
4D	77				EXT_SENS_	DATA_04[7:0]]		
4E	78				EXT_SENS_	DATA_05[7:0]]		
4F	79				EXT_SENS_	DATA_06[7:0]]		
50	80				EXT_SENS_	DATA_07[7:0]]		
51	81				EXT_SENS_	DATA_08[7:0]]		
52	82				EXT_SENS_	DATA_09[7:0]]		
53	83				EXT_SENS_	DATA_10[7:0]]		
54	84				EXT_SENS_	DATA_11[7:0]]		
55	85				EXT_SENS_	DATA_12[7:0]]		
56	86				EXT_SENS_	DATA_13[7:0]]		
57	87				EXT_SENS_	DATA_14[7:0]]		
58	88				EXT_SENS_	DATA_15[7:0]]		
59	89				EXT_SENS_	DATA_16[7:0]]		
5A	90				EXT_SENS_	DATA_17[7:0]]		
5B	91				EXT_SENS_	DATA_18[7:0]]		
5C	92				EXT_SENS_	DATA_19[7:0]]		
5D	93				EXT_SENS_	DATA_20[7:0]]		
5E	94		EXT_SENS_DATA_21[7:0]						
5F	95		EXT_SENS_DATA_22[7:0]						
60	96				EXT_SENS_	DATA_23[7:0]			

Description:

These registers store data read from external sensors by the Slave 0, 1, 2, and 3 on the auxiliary I²C interface. Data read by Slave 4 is stored in I2C_SLV4_DI (Register 53).

External sensor data is written to these registers at the Sample Rate as defined in Register 25. This access rate can be reduced by using the Slave Delay Enable registers (Register 103).

External sensor data registers, along with the gyroscope measurement registers, accelerometer measurement registers, and temperature measurement registers, are composed of two sets of registers: an internal register set and a user-facing read register set.

The data within the external sensors' internal register set is always updated at the Sample Rate (or the reduced access rate) whenever the serial interface is idle. This guarantees that a burst read of sensor registers will read measurements from the same sampling instant. Note that if burst reads are not used, the user is responsible for ensuring a set of single byte reads correspond to a single sampling instant by checking the Data Ready interrupt.

Data is placed in these external sensor data registers according to I2C_SLV0_CTRL, I2C_SLV1_CTRL, I2C_SLV2_CTRL, and I2C_SLV3_CTRL (Registers 39, 42, 45, and 48). When more than zero bytes are read ($I2C_SLVx_LEN > 0$) from an enabled slave ($I2C_SLVx_EN = 1$), the slave is read at the Sample Rate (as defined in Register 25) or delayed rate (if specified in Register 52 and 103). During each Sample cycle, slave reads are performed in order of Slave number. If all slaves are enabled with more than zero bytes to be read, the order will be Slave 0, followed by Slave 1, Slave 2, and Slave 3.



Each enabled slave will have EXT_SENS_DATA registers associated with it by number of bytes read (*I2C_SLVx_LEN*) in order of slave number, starting from EXT_SENS_DATA_00. Note that this means enabling or disabling a slave may change the higher numbered slaves' associated registers. Furthermore, if fewer total bytes are being read from the external sensors as a result of such a change, then the data remaining in the registers which no longer have an associated slave device (i.e. high numbered registers) will remain in these previously allocated registers unless reset.

If the sum of the read lengths of all SLVx transactions exceed the number of available EXT_SENS_DATA registers, the excess bytes will be dropped. There are 24 EXT_SENS_DATA registers and hence the total read lengths between all the slaves cannot be greater than 24 or some bytes will be lost.

<u>Note</u>: Slave 4's behavior is distinct from that of Slaves 0-3. For further information regarding the characteristics of Slave 4, please refer to Registers 49 to 53.

Example:

Suppose that Slave 0 is enabled with 4 bytes to be read ($I2C_SLV0_EN = 1$ and $I2C_SLV0_LEN = 4$) while Slave 1 is enabled with 2 bytes to be read, ($I2C_SLV1_EN=1$ and $I2C_SLV1_LEN = 2$). In such a situation, EXT_SENS_DATA _00 through _03 will be associated with Slave 0, while EXT_SENS_DATA _04 and 05 will be associated with Slave 1.

If Slave 2 is enabled as well, registers starting from EXT_SENS_DATA_06 will be allocated to Slave 2.

If Slave 2 is disabled while Slave 3 is enabled in this same situation, then registers starting from EXT_SENS_DATA_06 will be allocated to Slave 3 instead.

Register Allocation for Dynamic Disable vs. Normal Disable

If a slave is disabled at any time, the space initially allocated to the slave in the EXT_SENS_DATA register, will remain associated with that slave. This is to avoid dynamic adjustment of the register allocation.

The allocation of the EXT_SENS_DATA registers is recomputed only when (1) all slaves are disabled, or (2) the *I2C_MST_RST* bit is set (Register 106).

This above is also true if one of the slaves gets NACKed and stops functioning.



4.27 Register 97 – Motion Detection Status MOT_DETECT_STATUS

Type: Read Only

egister (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
61	97	MOT _XNEG	MOT _XPOS	MOT _YNEG	MOT _YPOS	MOT _ZNEG	MOT _ZPOS	-	MOT _ZRMOT

Description:

This register reports the status of Motion detection and Zero Motion detection.

The Motion detection bits, *MOT_XNEG*, *MOT_XPOS*, *MOT_YNEG*, *MOT_YPOS*, *MOT_ZNEG*, and *MOT_ZPOS*, report the axis and polarity of motion which generated a Motion Detection interrupt.

The MOT_ZRMOT bit is set to 1 when Zero Motion has been detected.

Reading this register clears the Motion detection bits. However, the *MOT_ZRMOT* bit does not clear until Zero Motion is no longer detected.

For more information regarding Motion detection and Zero Motion detection, please refer to Registers 31 to 34 in this document, as well as Sections 8.3 and 8.4 of the MPU-9150 Product Specification document.

Bit 1 is reserved.

Parameters:	
MOT_XNEG	This bit automatically sets to 1 when motion in the negative X axis has generated a Motion detection interrupt.
MOT_XPOS	This bit automatically sets to 1 when motion in the positive X axis has generated a Motion detection interrupt.
MOT_YNEG	This bit automatically sets to 1 when motion in the negative Y axis has generated a Motion detection interrupt.
MOT_YPOS	This bit automatically sets to 1 when motion in the positive Y axis has generated a Motion detection interrupt.
MOT_ZNEG	This bit automatically sets to 1 when motion in the negative Z axis has generated a Motion detection interrupt.
MOT_ZPOS	This bit automatically sets to 1 when motion in the positive Z axis has generated a Motion detection interrupt.
MOT_ZRMOT	This bit automatically sets to 1 when Zero Motion detection interrupt is generated.



4.28 Register 99 – I²C Slave 0 Data Out I2C_SLV0_DO

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
63	99				I2C_SLV	0_DO[7:0]			

Description:

This register holds the output data written into Slave 0 when Slave 0 is set to write mode.

For further information regarding Slave 0 control, please refer to Registers 37 to 39.

Parameters:

I2C_SLV0_D0 8 bit unsigned value that is written into Slave 0 when Slave 0 is set to write mode.

4.29 Register 100 – I²C Slave 1 Data Out I2C_SLV1_DO

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
64	100				I2C_SLV	1_DO[7:0]			

Description:

This register holds the output data written into Slave 1 when Slave 1 is set to write mode.

For further information regarding Slave 1 control, please refer to Registers 40 to 42.

Parameters:

I2C_SLV1_DO

8 bit unsigned value that is written into Slave 1 when Slave 1 is set to write mode.



4.30 Register 101 – I²C Slave 2 Data Out I2C_SLV2_DO

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
65	101				I2C_SLV	2_DO[7:0]			

Description:

This register holds the output data written into Slave 2 when Slave 2 is set to write mode.

For further information regarding Slave 2 control, please refer to Registers 43 to 45.

Parameters:

I2C_SLV2_D0 8 bit unsigned value that is written into Slave 2 when Slave 2 is set to write mode.

4.31 Register 102 – I²C Slave 3 Data Out I2C_SLV3_DO

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
66	102				I2C_SLV	3_DO[7:0]			

Description:

This register holds the output data written into Slave 3 when Slave 3 is set to write mode.

For further information regarding Slave 3 control, please refer to Registers 46 to 48.

Parameters:

I2C_SLV3_DO

8 bit unsigned value that is written into Slave 3 when Slave 3 is set to write mode.



4.32 Register 103 – I²C Master Delay Control I2C_MST_DELAY_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
67	103	DELAY _ES _SHADOW	-	-	I2C_SLV4 _DLY_EN	I2C_SLV3 _DLY_EN	I2C_SLV2 _DLY_EN	I2C_SLV1 _DLY_EN	I2C_SLV0 _DLY_EN

Description:

This register is used to specify the timing of external sensor data shadowing. The register is also used to decrease the access rate of slave devices relative to the Sample Rate.

When *DELAY_ES_SHADOW* is set to 1, shadowing of external sensor data is delayed until all data has been received.

When *I2C_SLV4_DLY_EN*, *I2C_SLV3_DLY_EN*, *I2C_SLV2_DLY_EN*, *I2C_SLV1_DLY_EN*, and *I2C_SLV0_DLY_EN* are enabled, the rate of access for the corresponding slave devices is reduced.

When a slave's access rate is decreased relative to the Sample Rate, the slave is accessed every

 $1 / (1 + I2C_MST_DLY)$ samples.

This base Sample Rate in turn is determined by *SMPLRT_DIV* (register 25) and *DLPF_CFG* (register 26).

For further information regarding I2C_MST_DLY, please refer to register 52.

For further information regarding the Sample Rate, please refer to register 25.

Bits 6 and 5 are reserved.

DELAY_ES_SHADOW	When set, delays shadowing of external sensor data until all data has been received.
I2C_SLV4_DLY_EN	When enabled, slave 4 will only be accessed at a decreased rate.
I2C_SLV3_DLY_EN	When enabled, slave 3 will only be accessed at a decreased rate.
I2C_SLV2_DLY_EN	When enabled, slave 2 will only be accessed at a decreased rate.
I2C_SLV1_DLY_EN	When enabled, slave 1 will only be accessed at a decreased rate.
I2C_SLV0_DLY_EN	When enabled, slave 0 will only be accessed at a decreased rate.



4.33 Register 104 – Signal Path Reset SIGNAL_PATH_RESET

Type: Write Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
68	104	-	-	-	-	-	GYRO _RESET	ACCEL _RESET	TEMP _RESET

Description:

This register is used to reset the analog and digital signal paths of the gyroscope, accelerometer, and temperature sensors.

The reset will revert the signal path analog to digital converters and filters to their power up configurations.

Note: This register does not clear the sensor registers.

Bits 7 through 3 are reserved.

GYRO_RESET	When set to 1, this bit resets the gyroscope analog and digital signal paths.
ACCEL_RESET	When set to 1, this bit resets the accelerometer analog and digital signal paths.
TEMP_RESET	When set to 1, this bit resets the temperature sensor analog and digital signal paths.

43 of 60



4.34 Register 105 – Motion Detection Control MOT_DETECT_CTRL

Type: Read/Write

	Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
Γ	69	105	-	-	ACCEL_ON	DELAY[1:0]	FF_COL	JNT[1:0]	MOT_CO	UNT[1:0]

Description:

This register is used to add delay to the accelerometer power on time. It is also used to configure the Free Fall and Motion detection decrement rate.

The accelerometer data path provides samples to the sensor registers, Motion detection, Zero Motion detection, and Free Fall detection modules. The signal path contains filters which must be flushed on wake-up with new samples before the detection modules begin operations. The default wake-up delay, of 4ms can be lengthened by up to 3ms. This additional delay is specified in *ACCEL_ON_DELAY* in units of 1 LSB = 1 ms. The user may select any value above zero unless instructed otherwise by InvenSense. Please refer to Section 8 of the MPU-9150 Product Specification document for further information regarding the detection modules.

Detection is registered by the Free Fall detection module or the Motion detection module after accelerometer measurements meet their respective threshold conditions over a specified number of samples. When the threshold conditions are met, the corresponding detection counter increments by 1. The user may control the rate at which the detection counter decrements when the threshold condition is not met by configuring *FF_COUNT* and *MOT_COUNT*. The decrement rate can be set according to the following table:

FF_COUNT or MOT_COUNT	Counter Decrement
0	Reset
1	1
2	2
3	4

When *FF_COUNT* or *MOT_COUNT* are configured to 0 (reset), any non-qualifying sample will reset the corresponding counter to 0. For further information on Free Fall detection and Motion detection, please refer to Registers 29 to 32.

Bits 7 and 6 are reserved.

ACCEL_ON_DELAY	2-bit unsigned value. Specifies the additional power-on delay applied to accelerometer data path modules.
	Unit of 1 LSB = 1 ms.
FF_COUNT	2-bit unsigned value. Configures the Free Fall detection counter decrement rate.
MOT_COUNT	2-bit unsigned value. Configures the Motion detection counter decrement rate.



4.35 Register 106 – User Control USER_CTRL

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
6A	106	-	FIFO_EN	I2C_MST _EN	I2C_IF _DIS	-	FIFO _RESET	I2C_MST _RESET	SIG_COND _RESET

Description:

This register allows the user to enable and disable the FIFO buffer, I^2C Master Mode, and primary I^2C interface. The FIFO buffer, I^2C Master, sensor signal paths and sensor registers can also be reset using this register.

When $I2C_MST_EN$ is set to 1, I²C Master Mode is enabled. In this mode, the MPU-9150 acts as the I²C Master to the external sensor slave devices on the auxiliary I²C bus. When this bit is cleared to 0, the auxiliary I²C bus lines (AUX_DA and AUX_CL) are logically driven by the primary I²C bus (SDA and SCL). This is a precondition to enabling Bypass Mode. For further information regarding Bypass Mode, please refer to Register 55.

Always write 0 to *I2C_IF_DIS* for the MPU-9150.

When the reset bits (*FIFO_RESET, I2C_MST_RESET, and SIG_COND_RESET*) are set to 1, these reset bits will trigger a reset and then clear to 0.

Bits 7 and 3 are reserved.

FIFO_EN	When set to 1, this bit enables FIFO operations.
	When this bit is cleared to 0, the FIFO buffer is disabled. The FIFO buffer cannot be written to or read from while disabled.
	The FIFO buffer's state does not change unless the MPU-9150 is power cycled.
I2C_MST_EN	When set to 1, this bit enables I ² C Master Mode.
5	When this bit is cleared to 0, the auxiliary I^2C bus lines (AUX_DA and AUX_CL) are logically driven by the primary I^2C bus (SDA and SCL).
I2C_IF_DIS	Always write this bit as zero.
FIFO_RESET	This bit resets the FIFO buffer <i>w</i> hen set to 1 while <i>FIFO_EN</i> equals 0. This bit automatically clears to 0 after the reset has been triggered.
I2C_MST_RESET	This bit resets the I^2C Master when set to 1 while $I2C_MST_EN$ equals 0. This bit automatically clears to 0 after the reset has been triggered.
SIG_COND_RESET	When set to 1, this bit resets the signal paths for all sensors (gyroscopes, accelerometers, and temperature sensor). This operation will also clear the sensor registers. This bit automatically clears to 0 after the reset has been triggered.
	When resetting only the signal path (and not the sensor registers), please use Register 104, SIGNAL_PATH_RESET.



4.36 Register 107 – Power Management 1 PWR_MGMT_1

Type: Read/Write

Regist (Hex)	r Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
6B	107	DEVICE _RESET	SLEEP	CYCLE	-	TEMP_DIS	CLKSEL[2:0]		

Description:

This register allows the user to configure the power mode and clock source. It also provides a bit for resetting the entire device, and a bit for disabling the temperature sensor.

By setting *SLEEP* to 1, the MPU-9150 can be put into low power sleep mode. When *CYCLE* is set to 1 while *SLEEP* is disabled, the MPU-9150 will be put into Cycle Mode. In Cycle Mode, the device cycles between sleep mode and waking up to take a single sample of data from active sensors at a rate determined by *LP_WAKE_CTRL* (register 108). To configure the wake frequency, use *LP_WAKE_CTRL* within the Power Management 2 register (Register 108).

An internal 8MHz oscillator, gyroscope based clock, or external sources can be selected as the MPU-9150 clock source. When the internal 8 MHz oscillator or an external source is chosen as the clock source, the MPU-9150 can operate in low power modes with the gyroscopes disabled.

Upon power up, the MPU-9150 clock source defaults to the internal oscillator. However, it is highly recommended that the device be configured to use one of the gyroscopes (or an external clock source) as the clock reference for improved stability. The clock source can be selected according to the following table.

CLKSEL	Clock Source
0	Internal 8MHz oscillator
1	PLL with X axis gyroscope reference
2	PLL with Y axis gyroscope reference
3	PLL with Z axis gyroscope reference
4	PLL with external 32.768kHz reference
5	PLL with external 19.2MHz reference
6	Reserved
7	Stops the clock and keeps the timing generator in reset

For further information regarding the MPU-9150 clock source, please refer to the MPU-9150 Product Specification document.

Bit 4 is reserved.



Parameters:	
DEVICE_RESET	When set to 1, this bit resets all internal registers to their default values.
	The bit automatically clears to 0 once the reset is done.
	The default values for each register can be found in Section 3.
SLEEP	When set to 1, this bit puts the MPU-9150 into sleep mode.
CYCLE	When this bit is set to 1 and <i>SLEEP</i> is disabled, the MPU-9150 will cycle between sleep mode and waking up to take a single sample of data from active sensors at a rate determined by <i>LP_WAKE_CTRL</i> (register 108).
TEMP_DIS	When set to 1, this bit disables the temperature sensor.
CLKSEL	3-bit unsigned value. Specifies the clock source of the device.



4.37 Register 108 – Power Management 2 PWR_MGMT_2

Type: Read/Write

Registe (Hex)	r Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
6C	108	LP_WAKE	_CTRL[1:0]	STBY_XA	STBY_YA	STBY_ZA	STBY_XG	STBY_YG	STBY_ZG

Description:

This register allows the user to configure the frequency of wake-ups in Accelerometer Only Low Power Mode. This register also allows the user to put individual axes of the accelerometer and gyroscope into standby mode.

The MPU-9150 can be put into Accelerometer Only Low Power Mode using the following steps:

- (i) Set CYCLE bit to 1
- (ii) Set SLEEP bit to 0
- (iii) Set TEMP_DIS bit to 1
- (iv) Set STBY_XG, STBY_YG, STBY_ZG bits to 1

All of the above bits can be found in Power Management 1 register (Register 107).

In this mode, the device will power off all devices except for the primary I²C interface, waking only the accelerometer at fixed intervals to take a single measurement. The frequency of wake-ups can be configured with *LP_WAKE_CTRL* as shown below.

Wake-up Frequency
1.25 Hz
5 Hz
20 Hz
40 Hz

For further information regarding the MPU-9150's power modes, please refer to Register 107.

The user can put individual accelerometer and gyroscopes axes into standby mode by using this register. If the device is using a gyroscope axis as the clock source and this axis is put into standby mode, the clock source will automatically be changed to the internal 8MHz oscillator.

Parameters:

LP_WAKE_CTRL 2-bit unsigned value. Specifies the frequency of wake-ups during Accelerometer Only Low Power Mode. STBY XA When set to 1, this bit puts the X axis accelerometer into standby mode. STBY YA When set to 1, this bit puts the Y axis accelerometer into standby mode. STBY ZA When set to 1, this bit puts the Z axis accelerometer into standby mode. STBY_XG When set to 1, this bit puts the X axis gyroscope into standby mode. STBY YG When set to 1, this bit puts the Y axis gyroscope into standby mode. STBY ZG When set to 1, this bit puts the Z axis gyroscope into standby mode.



4.38 Register 114 and 115 – FIFO Count Registers FIFO_COUNT_H and FIFO_COUNT_L

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0		
72	114	-	-	-	-	-	FIF	FIFO_COUNT[10:8]			
73	115		FIFO_COUNT[7:0]								

Description:

These registers keep track of the number of samples currently in the FIFO buffer.

These registers shadow the FIFO Count value. Both registers are loaded with the current sample count when FIFO_COUNT_H (Register 72) is read.

Note: Reading only FIFO_COUNT_L will not update the registers to the current sample count. FIFO_COUNT_H must be accessed first to update the contents of both these registers.

FIFO_COUNT should always be read in high-low order in order to guarantee that the most current FIFO Count value is read.

Parameters:

FIFO_COUNT

16-bit unsigned value. Indicates the number of bytes stored in the FIFO buffer. This number is in turn the number of bytes that can be read from the FIFO buffer and it is directly proportional to the number of samples available given the set of sensor data bound to be stored in the FIFO (register 35 and 36).



4.39 Register 116 – FIFO Read Write FIFO_R_W

Type: Read/Write

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
74	116				FIFO_D	ATA[7:0]			

Description:

This register is used to read and write data from the FIFO buffer.

Data is written to the FIFO in order of register number (from lowest to highest). If all the FIFO enable flags (see below) are enabled and all External Sensor Data registers (Registers 73 to 96) are associated with a Slave device, the contents of registers 59 through 96 will be written in order at the Sample Rate.

The contents of the sensor data registers (Registers 59 to 96) are written into the FIFO buffer when their corresponding FIFO enable flags are set to 1 in FIFO_EN (Register 35). An additional flag for the sensor data registers associated with I²C Slave 3 can be found in I2C_MST_CTRL (Register 36).

If the FIFO buffer has overflowed, the status bit *FIFO_OFLOW_INT* is automatically set to 1. This bit is located in INT_STATUS (Register 58). When the FIFO buffer has overflowed, the oldest data will be lost and new data will be written to the FIFO.

If the FIFO buffer is empty, reading this register will return the last byte that was previously read from the FIFO until new data is available. The user should check *FIFO_COUNT* to ensure that the FIFO buffer is not read when empty.

Parameters:

FIFO_DATA

8-bit data transferred to and from the FIFO buffer.



4.40 Register 117 – Who Am I WHO_AM_I

Type: Read Only

Register (Hex)	Register (Decimal)	Bit7	Bit6	Bit5	Bit4	Bit3	Bit2	Bit1	Bit0
75	117	-		WHO_AM_I[6:1]					

Description:

This register is used to verify the identity of the device. The contents of WHO_AM_I are the upper 6 bits of the MPU-9150's 7-bit I²C address. The least significant bit of the MPU-1950's I²C address is determined by the value of the AD0 pin. The value of the AD0 pin is not reflected in this register.

The default value of the register is 0x68.

Bits 0 and 7 are reserved. (Hard coded to 0)

Parameters:

WHO_AM_I

Contains the 6-bit I²C address of the MPU-9150.

The Power-On-Reset value of Bit6:Bit1 is 110 100.



5 Register Map for Magnetometer

The register map for the MPU-9150's Magnetometer (AK8975C) section is listed below. The Register Map of the Gyroscope and Accelerometer section is in section 3.

Name	Address	READ/ WRITE	Description	Bit width	Explanation
WIA	00H	READ	Device ID	8	
INFO	01H	READ	Information	8	
ST1	02H	READ	Status 1	8	Data status
HXL	03H			8	X-axis data
НХН	04H			8	X-axis data
HYL	05H	READ	Measurement data	8	Mary in state
HYH	06H	I LI LI		8	Y-axis data
HZL	07H			8	Z-axis data
HZH	08H			8	
ST2	09H	READ	Status 2	8	Data status
CNTL	0AH	READ/WR ITE	Control	8	
RSV	0BH	READ/ WRITE	Reserved	8	DO NOT ACCESS
ASTC	0CH	READ/ WRITE	Self-test	8	
TS1	0DH	READ/ WRITE	Test 1	8	DO NOT ACCESS
TS2	0EH	READ/ WRITE	Test 2	8	DO NOT ACCESS
I2CDIS	0FH	READ/ WRITE	l ² C disable	8	
ASAX	10H	READ	X-axis sensitivity adjustment value	8	Fuse ROM
ASAY	11H	READ	Y-axis sensitivity adjustment value	8	Fuse ROM
ASAZ	12H	READ	Z-axis sensitivity adjustment value	8	Fuse ROM

Addresses from 00H to 0CH and from 10H to 12H are compliant with automatic increment function of serial interface respectively. Values of addresses from 10H to 12H can be read only in Fuse access mode. In other modes, read data is not correct.



5.1 Register Map Description

Addr	Register Name	D7	D6	D5	D4	D3	D2	D1	D0
Read-on	ly Register							-	
00H	WIA	0	1	0	0	1	0	0	0
01H	INFO	INF07	INFO6	INFO5	INFO4	INFO3	INFO2	INFO1	INF00
02H	ST1	0	0	0	0	0	0	0	DRDY
03H	HXL	HX7	HX6	HX5	HX4	HX3	HX2	HX1	HX0
04H	НХН	HX15	HX14	HX13	HX12	HX11	HX10	HX9	HX8
05H	HYL	HY7	HY6	HY5	HY4	HY3	HY2	HY1	HY0
06H	HYH	HY15	HY14	HY13	HY12	HY11	HY10	HY9	HY8
07H	HZL	HZ7	HZ6	HZ5	HZ4	HZ3	HZ2	HZ1	HZ0
08H	HZH	HZ15	HZ14	HZ13	HZ12	HZ11	HZ10	HZ9	HZ8
09H	ST2	0	0	0	0	HOFL	DERR	0	0
Write/rea	ad Register								
0AH	CNTL	0	0	0	0	MODE3	MODE2	MODE1	MODE0
0BH	RSV	-	-	-	-	-		-	-
0CH	ASTC	-	SELF	-	-	-		-	-
0DH	TS1	-	-	-	-	-	-	-	-
0EH	TS2	-	-	-	-		-	-	-
0FH	I2CDIS	-	-	-			-	-	I2CDIS
Read-on	ly Register						7		
10H	ASAX	COEFX7	COEFX6	COEFX5	COEFX4	COEFX3	COEFX2	COEFX1	COEFX0
11H	ASAY	COEFY7	COEFY6	COEFY5	COEFY4	COEFY3	COEFY2	COEFY1	COEFY0
12H	ASAZ	COEFZ7	COEFZ6	COEFZ5	COEFZ4	COEFZ3	COEFZ2	COEFZ1	COEFZ0

Note: When VDD is turned ON, POR function works and all registers of AK8975C are initialized .

TS1 and TS2 are test registers for shipment test. Do not use these registers.

RSV is reserved register. Do not use this register.





6 Register Detailed Descriptions for Magnetometer

This section details each register within the MPU-9150's Magnetometer section.

6.1 WIA: Device ID

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
00H	WIA	0	1	0	0	1	0	0	0			

Device ID of AKM. It is described in one byte and fixed value.

48H: fixed

6.2 INFO: Information

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0		
Read-only register											
01H	INFO	INFO3	INFO2	INFO1	INFO0						

INFO[7:0]: Device information for AKM.

6.3 ST1: Status 1

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
02H	02H ST1 0 0 0 0 0 0 0 DRDY											
	Reset	0	0	0	0	0	0	0	0			

DRDY: Data Ready

"0": Normal

"1": Data is ready

DRDY bit turns to "1" when data is ready in single measurement mode or self-test mode. It returns to "0" when any one of ST2 register or measurement data register (HXL to HZH) is read.



Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0		
	Read-only register										
03H	HXL	HX7	HX6	HX5	HX4	HX3	HX2	HX1	HX0		
04H	HXH	HX15	HX14	HX13	HX12	HX11	HX10	HX9	HX8		
05H	HYL	HY7	HY6	HY5	HY4	HY3	HY2	HY1	HY0		
06H	HYH	HY15	HY14	HY13	HY12	HY11	HY10	HY9	HY8		
07H	HZL	HZ7	HZ6	HZ5	HZ4	HZ3	HZ2	HZ1	HZ0		
08H	HZH	HZ15	HZ14	HZ13	HZ12	HZ11	HZ10	HZ9	HZ8		
	Reset	0	0	0	0	0	0	0	0		

6.4 HXL to HZH: Measurement Data

Measurement data of magnetic sensor X-axis/Y-axis/Z-axis

HXL[7:0]: X-axis measurement data lower 8bit HXH[15:8]: X-axis measurement data higher 8bit HYL[7:0]: Y-axis measurement data lower 8bit HYH[15:8]: Y-axis measurement data higher 8bit HZL[7:0]: Z-axis measurement data lower 8bit HZH[15:8]: Z-axis measurement data higher 8bit

Measurement data is stored in two's complement and Little Endian format. Measurement range of each axis is from -4096 to +4095 in decimal.

Measurement	data (each axis) [1	5:0]	Magnetic flux density [µT]								
Two's complement	Hex	Decimal									
0000 1111 1111 1111	OFFF	4095	1229(max.)								
0000 0000 0000 0001	0001	1	0.3								
0000 0000 0000 0000	0000	0	0								
1111 1111 1111 1111	FFFF	-1	-0.3								
1111 0000 0000 0000	F000	-4096	-1229(min.)								



6.5 ST2: Status 2

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
09H	ST2	0	0	0	0	HOFL	DERR	0	0			
Reset		0	0	0	0	0	0	0	0			

DERR: Data Error

- "0": Normal
- "1": Data read error occurred

When data reading is started out of data readable period, the read data are not correct. In this case, data read error occurs and DERR bit turns to "1". When ST2 register is read, it returns to "0".

HOFL: Magnetic sensor overflow

- "0": Normal
- "1": Magnetic sensor overflow occurred

In single measurement mode and self-test mode, magnetic sensor may overflow even though measurement data regiseter is not saturated. In this case, measurement data is not correct and HOFL bit turns to "1". When next measurement stars, it returns to "0".

6.6	CNTL: Control										
Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0		
	Read-only register										
0AH	CNTL	0	0	0	0	MODE3	MODE2	MODE1	MODE0		
	Reset	0	0	0	0	0	0	0	0		

MODE[3:0]: Operation mode setting

"0000": Power-down mode

"0001": Single measurement mode

"1000": Self-test mode

"1111": Fuse ROM access mode

Other code settings are prohibited

When each mode is set, AK8975C transits to set mode.

When CNTL register is accessed to be written, registers from 02H to 09H are initialized.



6.7 RSV: Reserved

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Read-only register											
0BH	RSV	-	-	-	-	-	-	-	-			
	Reset	0	0	0	0	0	0	0	0			

RSV register is reserved. Do not use this register.

6.8 ASTC: Self Test Control

•.•											
Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0		
	Write/read register										
0CH ASTC - SELF								-			
	Reset	0	0	0	0	0	0	0	0		

SELF: Self test control

- "0": Normal
- "1": Generate magnetic field for self-test

Do not write "1" to any bit other than SELF bit in ASTC register. If "1" is written to any bit other than SELF bit, normal measurement cannot be done.

6.9 TS1, TS2: Test 1, 2

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0			
	Write/read register											
0DH	TS1	-	-	-	-	-	-	-	-			
0EH	TS2	-	-	-	-	-	-	-	-			
	Reset	0	0	0	0	0	0	0	0			

TS1 and TS2 registers are test registers for shipment test. Do not use these registers.

6.10 I2CDIS: I²C Disable

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0
Write/read register									
0FH	I2CDIS	-	-	-	-	-	-	-	I2CDIS
Reset		0	0	0	0	0	0	0	0

This register disables I^2C bus interface. I^2C bus interface is enabled in default. To disable I^2C bus interface, write "00011011" to I2CDIS register. Then I2CDIS bit turns to "1" and I^2C bus interface is disabled.

Once I2CDIS is turned to "1" and I²C bus interface is disabled, re-setting I2CDIST to "0" is prohibited. To enable I²C bus interface, reset AK8975C by turning VDD to OFF (0V) once.



6.11 ASAX, ASAY, ASAZ: Sensitivity Adjustment values

Addr	Register name	D7	D6	D5	D4	D3	D2	D1	D0
Read-only register									
10H	ASAX	COEFX7	COEFX6	COEFX5	COEFX4	COEFX3	COEFX2	COEFX1	COEFX0
11H	ASAY	COEFY7	COEFY6	COEFY5	COEFY4	COEFY3	COEFY2	COEFY1	COEFY0
12H	ASAZ	COEFZ7	COEFZ6	COEFZ5	COEFZ4	COEFZ3	COEFZ2	COEFZ1	COEFZ0
Reset		-	-	-	-	-	-	-	-

Sensitivity adjustment data for each axis is stored to fuse ROM on shipment.

ASAX[7:0]: M	lagnetic sensor X-axis sensitivit	y adjustment value
--------------	-----------------------------------	--------------------

ASAY[7:0]: Magnetic sensor Y-axis sensitivity adjustment value

ASAZ[7:0]: Magnetic sensor Z-axis sensitivity adjustment value

Sensitivity Adjustment

The sensitivity adjustment is done by the equation below;

$$Hadj = H \times \left(\frac{(ASA - 128) \times 0.5}{128} + 1\right)$$

where *H* is the measurement data read out from the measurement data register, *ASA* is the sensitivity adjustment value, and *Hadj* is the adjusted measurement data.



This information furnished by InvenSense is believed to be accurate and reliable. However, no responsibility is assumed by InvenSense for its use, or for any infringements of patents or other rights of third parties that may result from its use. Specifications are subject to change without notice. InvenSense reserves the right to make changes to this product, including its circuits and software, in order to improve its design and/or performance, without prior notice. InvenSense makes no warranties, neither expressed nor implied, regarding the information and specifications contained in this document. InvenSense assumes no responsibility for any claims or damages arising from information contained in this document, or from the use of products and services detailed therein. This includes, but is not limited to, claims or damages based on the infringement of patents, copyrights, mask work and/or other intellectual property rights.

Certain intellectual property owned by InvenSense and described in this document is patent protected. No license is granted by implication or otherwise under any patent or patent rights of InvenSense. This publication supersedes and replaces all information previously supplied. Trademarks that are registered trademarks are the property of their respective companies. InvenSense sensors should not be used or sold in the development, storage, production or utilization of any conventional or mass-destructive weapons or for any other weapons or life threatening applications, as well as in any other life critical applications such as medical equipment, transportation, aerospace and nuclear instruments, undersea equipment, power plant equipment, disaster prevention and crime prevention equipment.

InvenSense®, is a registered trademark of InvenSense, Inc. MPU[™], MPU-9150[™], MPU-6050[™], MPU-3050[™], IMU-3000[™], Motion Processing Unit[™], MotionFusion[™], MotionProcessing[™], MotionApps[™], Digital Motion Processor[™], Digital Motion Processing[™], and DMP[™] are trademarks of InvenSense, Inc.

©2011 InvenSense, Inc. All rights reserved.

